




The Only Factory Authorized Repair Center for Superior Electric Stepper Drive & Motor Repair

Motor Systems Inc.
460 Milford Parkway
Milford, OH . 45150
www.motorsystems.com
513-576-1725

PRICE: \$25.00

INSTRUCTIONS for **SLO-SYN® MICRO-SERIES MOTION CONTROLS** **PROGRAMMABLE INDEXERS** **TYPES 3180-PI, 3180-PI10, 3180-PI125**



©1987, The Superior Electric Company

EXPRESS START-UP PROCEDURE

STEPS NECESSARY TO BECOME OPERATIONAL

The following are the minimum steps necessary for the Packaged Indexer to become operational. **FAILURE TO PERFORM THESE STEPS MAY RESULT IN DAMAGE TO THE UNIT.**

I. DRIVE

Failure to properly perform the steps listed below will result in damage to the drive or injury to personnel.

1. Connect 120 volts ac, 50/60 hertz to the AC input terminal strip. The terminal labeled "H" is hot, "C" is common and "G" is ground.
2. Check to see that the motor used is compatible with the drive. A list of compatible motors is given in Section 3.3 of this manual.
3. Set the correct current level for the motor being used per the instructions in Section 3.8 of this manual.
4. Wire the motor per Section 2.2, "Motor Connections" in this manual.
5. **Caution:** always disconnect the ac power to the unit when connecting or disconnecting the motor connector or leads. **Be certain the "PWR ON" LED is OFF before unplugging the motor connector, or the drive will be damaged.**
6. **Caution:** The motor and drive must always be **grounded** during operation. Be sure to twist the wires for each motor phase. Six twists per foot is a good guideline.
7. Connect parallel interface data to J5 and serial data to J4. The SSP-100 Indexer Programmer is a parallel interface device and the SSP-500 Indexer Programmer is a serial interface device. Refer to Sections 4 and 5 of the manual for information and operating instructions.

II. INDEXER

This instruction manual **MUST BE READ IN ITS ENTIRETY** to correctly operate the indexer. This Express Start-Up Procedure only highlights the important items necessary to ensure correct operation of the Indexer.

1. **SPECIFICATIONS** - Be certain that your signals which communicate with the Indexer meet the following specifications (more details are found in Section 3.6 of this manual).

A. SERIAL (RS232) OPERATION

1. **SPECIFICATIONS** - Be certain that the following signal specifications are met:

RS232 signal characteristics:

Output voltage swing: ± 5 Vdc minimum; ± 10 Vdc maximum
Input voltage range: -30 Vdc minimum; +30 Vdc maximum

2. **CONNECTIONS** - The serial port (9-pin "D" connector) is designated as follows:

Pin	Assignment
1	Signal Common
2	RS232 Chain Out
3	RS232 Receive Data
4	Signal Common
5	Signal Common
6	RS232 Echo
7	RS232 Chain In
8	+5 Vdc
9	+5 Vdc

Connect the host computer or terminal as shown in Figure 2.4 of this manual for single indexer interfacing or as in Figure 2.5 for daisy-chain operation. **Use caution when connecting the indexer to the host device as +5 Vdc is present on the connector.** Only use the +5 Vdc for operation with the SSP-500 hand-held pendant. This connection is already made in the cable.

3. **COMMUNICATIONS** - Configure the RS232 communication parameters to correspond to the protocol of the host device. The indexer utilizes the Xon/Xoff handshaking technique which should be followed to ensure proper serial communications. The indexer must be addressed with the proper attention character (e.g., "<") and the device identification number (e.g., indexer #01) that is contained in parameter L21 to initiate communications.

4. **PROGRAMMING** - Always program L70, the step resolution parameter, first, followed by the remainder of the parameters. Carefully read Section 4 to implement the powerful and varied instruction set. Factory defaults have been set for your unit to aid in first-time operation. These are listed in Section 4.3 of the manual.

5. **EXECUTION** - The indexer executes its program based on the present settings of the various modes. If program or manual operations are not correct, verify the mode and parameter settings. The Trace mode is a valuable aid in observing program operation.

If the motor operates erratically, the motion parameters may need adjusting.

B PARALLEL OPERATION

1. **SPECIFICATIONS** - Be certain that your signals which communicate with the indexer meet the following specifications (more details are found in Section 3.6 of the manual).

Input Characteristics:

High Level (inactive) Voltage: +8.5 Vdc minimum, +15.0 Vdc maximum
High Level Current: 1 milliampere maximum leakage
Low Level (Active) Voltage: +0.0 Vdc minimum, +6.5 Vdc maximum
Low Level Current: 3.5 milliamperes maximum

Output Characteristics:

High Level (inactive) Voltage: +24.0 Vdc maximum, open collector

High Level Leakage Current: 250 microamperes maximum leakage

Low Level Output: +0.4 Vdc at 16 milliamperes sink current
+0.7 Vdc at 40 milliamperes sink current

2. CONNECTIONS - The parallel signals are obtained via the 25-pin "D" type connector. The pin assignments are as follows:

Pin	Assignment	Pin	Assignment
1	Signal Common	14	Signal Common
2	D7 Input*	15	D5 Input*
3	D5 Input*	16	D4 Input*
4	D3 Input*	17	D2 Input*
5	D1 Input*	18	D0 Input*
6	Motion Busy*†	19	Not Used
7	Strobe 7*	20	Strobe 6*
8	Strobe 5*	21	Strobe 4*
9	Strobe 3*	22	Strobe 2*
10	Strobe 1*	23	Strobe 0*
11	Output 2*†	24	Output 1*†
12	All Windings Off Output*†	25	Pulse Output*†
13	Direction Output*†		

* Signals are active when low, inactive when high.

† Open collector output.

An example of a switch panel interface is displayed in Figure 5.2. The **diodes must be included** for the indexer to operate successfully.

3. COMMUNICATIONS - Proper parallel operation must observe the timing requirements as shown in Figure 5.3. The L07 parameter determines the timing of the strobes during the load sequence.

4. PROGRAMMING - L70, the step resolution parameter, must be programmed first, after which the rest of the parameters may be programmed. Carefully read Sections 4 and 5 of the manual to learn how to implement the powerful and varied instruction set. Factory default values have been set for your unit to aid in first-time operation. These default values are listed in Section 4.3 of the manual.

5. EXECUTION - The indexer executes based on the present settings of the various modes. If program or manual operations are not correct, verify the mode and parameter settings.

If the motor operates erratically, adjust the motion parameters.

**FUSE AND MOTOR CONNECTOR PART NUMBERS
FOR 3180 SERIES UNITS**

FUSE: Littelfuse part number 225005
2AG, 5 amperes, 125 volts, fast acting

MOTOR CONNECTOR (mates with female motor connector on drive)

Male connector body: AMP part number 206434-1
Pins (5 required): AMP part number 66506-8
Cable clamp: AMP part number 206062-1

INSTALLATION GUIDELINES FOR REDUCED NOISE INTERFERENCE

I General Comments

SLO-SYN Micro Series drives use modern solid-state electronics such as microprocessors to provide the features needed for advanced motion control applications. In some cases, these applications produce electromagnetic interference (EMI, or electrical "noise") that may cause inappropriate operation of the microprocessor logic used in the Micro Series product, or in any other computer-type equipment in the user's system.

This guide is aimed toward helping users avoid such problems by applying "good engineering practices" when designing their systems. Following these guidelines will usually prevent EMI noise from interfering with drive operation.

II Noise Sources

What causes electrical noise? In general, any equipment that causes arcs or sparks or that switches voltage or current at high frequencies can cause interference. In addition, ac utility lines are often "polluted" with electrical noise from sources outside a user's control (such as equipment in the factory next door).


The following are some of the more common causes of electrical interference:

- power from the utility ac line
- relays, contactors and solenoids
- light dimmers
- arc welders
- motors and motor starters
- induction heaters
- radio controls or transmitters
- switch-mode power supplies
- computer-based equipment
- high frequency lighting equipment
- dc servo and stepper motors and drives

III Mounting Location

When selecting a mounting location, it is preferable to keep the drive away from obvious noise sources, such as those listed above. If possible, locate the drive in its own metal enclosure to shield it and its wiring from noise sources. If this cannot be done, keep the drive at least three feet from any noise sources.

Recommended Wiring Practices



IV Wiring Practices - "Dos and Don'ts"

Do the following when installing or wiring your drive or indexer:

- **Do** keep the drive and its wiring as far away from noise sources as possible.
- **Do** provide a good, solid ground connection to the ac system earth ground conductor. Bond the drive case to the system enclosure.
- **Do** use a single-point grounding scheme for all related components of a system (this looks like a "hub and spokes" arrangement).
- **Do** keep the ground connection short and direct.
- **Do** use a line filter on the ac input (Corcom type 10B1, 10S1 or 10K1 or equivalent) for noisy ac lines. Particularly bad ac lines may need to be conditioned with a ferroresonant type isolation transformer to provide "clean" power to the drive or indexer.
- **Do** keep signal and drive wiring well separated. If the wires must cross, they should do so at right angles to minimize coupling. Power wiring includes ac wiring, motor wiring, etc. and signal wiring includes inputs and outputs (I/O), serial communications (RS232 lines), etc.

- **Do** use separate conduits or ducts for signal and I/O wiring. Keep all power wiring out of these signal line conduits.
- **Do** use shielded, twisted-pair cables for indexer I/O lines.
- **Do** ground shields only at **one end**, the indexer/drive end.
- **Do** use twisted-pair, shielded cable for the motor wiring.
- **Do** use solid-state relays instead of electromechanical contact types wherever possible to minimize noise generation.
- **Do** suppress all relays to prevent noise generation. Typical suppressors are capacitors or MOV's. See manufacturers literature for complete information.

Do not do the following when installing your drive or indexer:

- **Do not** install sensitive computer-based equipment (such as an indexer/drive) near a source of electromagnetic noise.
- **Do not** bundle power and signal lines together.
- **Do not** bundle motor cables and signal lines together.
- **Do not** fail to use shielded, twisted-pair cables for signals.
- **Do not** fail to properly connect the system grounds.
- **Do not** use "daisy-chained" grounds.
- **Do not** fail to ground signal cable shields at only one end.
- **Do not** assume that power from the ac line is adequately "clean".

V AC Line Filter

Use of an AC line filter on 3180 and 6180 Series drives is **recommended**. A suitable filter is included with each unit supplied for sale in North America.

Proper installation of the AC Line Filter is essential




WARNING: Improper installation of the ac line filter may cause electrical shock, which could result in death, serious bodily injury or property damage. To avoid electrical shock:

- The ac line filter must be installed by qualified personnel. Typical methods of locating and installing the line filter are shown in Figures 1 and 2.
- The ac line filter must be firmly fastened near the Indexer. Failure to do so may result in damage to the filter and system.
- The installer must properly insulate and protect the ac connections to assure that the wires are not exposed. Exposed wires could cause electrical shock, resulting in death, bodily injury or property damage.

If you have any questions regarding installation of the line filter, contact an electrician before installing the device.

For best performance:

- The wire between the Filter and the Drive should be less than two feet (0.61 meter) long.



Proper AC Line Filter Connections

VI Troubleshooting Guide

Electrical interference problems are common with today's computer-based controls, and such problems are often difficult to diagnose and cure. If such a problem occurs with your system, it is recommended that the following checks be made to locate the cause of the problem.

1. Check the quality of the ac line voltage using an oscilloscope and a line monitor, such as the Superior Electric VMS series. If line voltage problems exist, use appropriate line conditioning, such as line filters or isolation transformers.
2. Be certain all of the previous Do's and Don'ts are followed for location, grounding, wiring and relay suppression.
3. Double check the grounding connections to be sure they are good electrical connections and are as short and direct as possible.
4. Try operating the drive with all suspected noise sources switched off. If the drive functions properly, switch the noise sources on again, one at a time, and try to isolate which ones are causing the interference problems. When a noise source is located, try rerouting wiring, suppressing relays or other measures to eliminate the problem.




FIGURE 1
Filter Installed On Fabricated Plate Mounted On Indexer




FIGURE 2
Filter Mounted Adjacent To Indexer

TABLE OF CONTENTS

	PAGE
PRECAUTIONS	9
WARNINGS, CAUTIONS, LIMITS OF USE, ETC.	9
SECTION 1: INTRODUCTION	10
1.1 Features Overview	10
1.2 Inspection parts list	10
1.3 Using this manual	10
1.3.1 Organization	10
1.3.2 Logic voltage and programming conventions	10
1.3.3 Indicator lights and AC fuse	10
SECTION 2: MOUNTING, CONNECTIONS & PIN ASSIGNMENTS	11
2.1 Mounting	11
2.2 Motor connections	11
2.3 Connection Diagrams	13
2.3.1 J1: Not Used	13
2.3.2 J2: Motor	13
2.3.3 J3: Power Input	13
2.3.4 J4: Parallel I/O	13
2.3.5 J5: Serial I/O	13
2.4 Serial Communication Connection Diagrams	13
2.4.1 Single Indexer System	13
2.4.2 Multiple Indexer System	14
2.5 Memory Protect Switch	14
SECTION 3: SPECIFICATIONS	15
3.1 Drive Description	15
3.2 Drive Performance	15
3.3 Motor Compatibility	15
3.4 Drive Mechanical Specifications	15
3.5 Electrical Specifications	15
3.5.1 AC Input	15
3.5.2 Output to Motor	15
3.6 Micro-Series-Indexer I/O Signal Interfaces	15
3.6.1 Parallel I/O	15
3.6.1.1 Parallel Output Characteristics	16
3.6.1.2 Parallel Input Characteristics	16
3.6.2 Serial I/O	16
3.7 Environmental Specifications	16
3.8 Current Settings	16
SECTION 4: PROGRAMMING GUIDE	17
4.1 Overview and Set-Up	17
4.1.2 General Programming Comments	17
4.1.3 Programming Chart	17
4.2 Immediate Commands	19
Clear	19
Freehold	19
Device Attention Character	19
Cycle Stop	19
Backspace and Delete	19
Delete Line	19
4.3 L Codes: Indexer Parameters	19
L06, Program Execution Format	20
L07, Strobe Delay Time	20
L08, Mechanical Home Direction	20
L09, Jog Speed	20
L11, Acceleration/Deceleration	21
L12, Low Speed	21
L14, Home Speed	21
L17, Offset Direction and Distance from Mechanical Home	21
L18, Clockwise Software Travel Limit	21
L19, Counterclockwise Software Travel Limit	22
L21, Assign Device Identification Number	22
L22, Baud Rate	22
L23, Character Length	22
L25, Parity	22
L26, Indexer Ready Acknowledge	22
L41, Auto Start Line Number	23
L44, Program Line Delay	23
L45, Limit Switch Enable	23
L48, Program Line Transfer Count	23
L49, Parameter Transfer Designation	23
L70, Translator Resolution	23
4.4 Codes: Commands for Modes of Operation	23
H1, Cycle Start	24
H2, Step Mode	24
H3, Jog Mode	24
H4, High Speed Mode	24
H5, Low Speed Mode	24
H6, Turn in CW Direction	24
H7, turn in CCW Direction	24
H8, Return to Electrical Home	24

	PAGE
H9, Set Electrical Home	24
H10, Return to Mechanical Home	24
H11, Clear Present Program Line	25
H12, Clear Program	25
H13, Transmit Contents of Present Program Line	25
H14, Transmit Program	25
H15, Transmit The Current Program Line Number	25
H16, Transmit Parameters	25
H17, Transmit Absolute Position	26
H18, Transmit Motion Status	26
H19, Transmit Mode Status	27
H20, Transmit I/O Status	28
H23, Transmit Software Revision Date	28
H24, Enable Trace Mode	28
H25, Disable Trace Mode	28
4.5 Programming Codes	28
N Codes, Line Number	28
X Codes, Move Direction and Distance	28
F Codes, Feedrate	28
G Codes, Programmable Commands	28
G04, Dwell Time	29
G11, Call a Subroutine	29
G20, Conditional Branch	29
G22, Wait for Input	30
G30, Return from Subroutine ProgramLine	31
G31, Program Stop	31
G36, Strobe X Code Data	31
G37, Strobe N Code Data	31
G47, Set Output	32
G64, Enable Reduced Current	32
G65, Cancel Reduced Current	32
G66, Enable Boost Current	32
G67, Cancel Boost Current	32
G68, Enable All Windings Off	32
G69, Cancel All Windings Off	32
G76, Return to Electrical Home	32
G77, Set Electrical Home	32
G78, Return to Mechanical Home	32
G90 , Absolute Mode	32
G91, Incremental Mode	32
4.6 Sample Program	33
4.7 Code Assignment Tables	34
SECTION 5: OPERATING INSTRUCTIONS	36
5.1 Overview	36
5.2 Operation from a Switch Panel	36
5.3 Operation from a Remote Terminal	41
5.4 Operation from a Host Computer	41
SECTION 6: SPEED/TORQUE CURVES	44
6.1 Motor Performance	49
SECTION 7: TROUBLESHOOTING	50
Summary of Codes	53
Program Worksheet	54

WARNINGS

- Voltages present in this unit can cause serious or fatal injury. Only qualified personnel should install or perform servicing procedures on this equipment.
- Voltage is present on unprotected pins when unit is operational.
- No short circuit protection for motor outputs is provided in this unit. The AC input is internally fused.
- Before making changes to the motor or control wiring, turn off all power to the unit, and disconnect its AC power source.
- Allow at least ten minutes for capacitors to discharge as they will remain at high voltages for several minutes after power is removed.

CAUTIONS:

- Assure motor compatibility before using the unit.
- Observe all cooling and temperature limitations. Heat sink temperature must be maintained between 0 and 80 degrees C. (32 and 176 degrees F). Unit must not be operated in ambient temperature below 0 degrees C (32 degrees F) or above 50 degrees C (122 degrees F).
- All Windings Off should be used with caution, as all holding torque is lost.

- Do not connect or disconnect motor or signal cables while AC power is applied.
- Do not use J1 connector (15-pin "D" connector).
- Do not exceed specified input voltage.
- Do not operate unit without the enclosures in place, as high voltages are present.

LIMITS OF USE:

- Reconfiguration of the circuit in any fashion not shown in this manual will void the warranty.

NOTES:

1. Clockwise and counterclockwise directions are properly oriented when viewing the motor from the label end.
2. When connecting the unit to a terminal or host computer, be sure to make note of the RS232 configuration and Micro-Series Indexer device address.
3. Care must be taken when connecting this unit to a host computer or remote terminal as a +5VDC voltage source is present on the RS232 connector. Follow instructions carefully.
4. The J1 connector (15 pin "D" connector) is not to be used for any purpose.

SECTION 1: INTRODUCTION

1.1 FEATURES OVERVIEW

The 3180-PI provides the following output capability:

MOTOR CURRENT PER PHASE	VA PER PHASE
3180-PI 3 Amps peak	500 VA nominal

The 3180-PI motor drive/indexer package is a line-operated, energy efficient motor drive module, that is coupled to a programmable microcontroller indexer. An integral power supply provides the necessary DC voltages required to operate the indexer and drive. This indexer/driver module is capable of driving a wide range of Superior Electric SLO-SYN stepping motors, and allows for a wide range of functions. The indexer has several features, including:

- Programming is done in a simple, easy to use format.
- Up to 400 lines of program instructions can be stored.
- Program storage is in nonvolatile memory
- Easy programming allows for motion and input/output control
- Up to 99 indexers may be daisy chained via RS232 communications.
- Program entry and execution may be done in a variety of ways:
Switch panel, including the Superior Electric SSP-100 SLO-SYN Indexer Programmer.
Remote terminal, including the Superior Electric SSP-500 SLO-SYN Indexer Programmer.
Host computer.

The drive features include:

- Full/half, 1/10, or 1/125 step resolution, depending on model.
- Motor current adjustable from 0.5 to 3.0 amperes per phase.
- Speeds up to 10,000 full steps per second.
- Reduce-current and boost-current functions that are indexer-controlled.
- Power-on and fault LED indicators
- Over-temperature protection.

1.2 INSPECTION PARTS LIST

The drive and indexer come fully assembled as a single unit that is marked with the part number, either 3180-PI (full/half step), 3180-PI10 (1/10 microstep), or 3180-PI125 (1/125 microstep).

1.3 USING THIS MANUAL

This manual is an installation and operating guide to the 3180-PI motor drive and indexer. All the necessary information is provided for using the 3180-PI successfully.

We strongly recommend that this manual be read thoroughly and completely before attempting to install and operate the equipment.

1.3.1 ORGANIZATION

This manual is organized for the convenience of the operator. Section 2, "mounting, Connections, and Pin Assignments," provides diagrams and reminders that are necessary, even for the experienced user and installer.

Complete specifications, listed in Section 3, will provide easily referenced information concerning all aspects of installation, power and interface requirements, as well a performance specifications.

Section 4 is a "Programming Guide" that explains all the parameters and commands used by the indexer, and gives examples of how these commands are used.

Section 5, entitled "Operating Instructions" provides information on how to operate the indexer from a switch panel, remote terminal or host computer. Detailed information on switch and strobe settings will be provided there.

The remaining sections contain additional drawings and information useful for setting up and operating the indexer modules.

1.3.2 LOGIC VOLTAGE AND PROGRAMMING CONVENTIONS

- All logic is LOW TRUE. This means that a logic function is **active when low** and inactive when high. The **low** true condition is designated by a bar. In the case of step/jog, jog is active when low. If a logic control function connector pin is left **open**, the function will be clamped in a **high or inactive** condition.
- When a sign is to be used in conjunction with a move distance or an offset direction, + will cause **clockwise** motion as viewed from the motor's LABEL END.
- Certain commands are designated as MODE commands. Examples: ABSOLUTE MODE, INCREMENTAL MODE, STEP MODE, JOG MODE, etc. Care should be taken to assure that the correct MODE is operational for each command. Once a mode is set, it remains active until a canceling or alternate mode is chosen.
- Motion performance and the ranges listed for motion parameters are dependent on the translator resolution chosen with the L70 parameter. **L70 must be programmed prior to any motion parameter entry. If the L70 parameter is modified, then the motion parameters must be re-entered.**

1.3.3 INDICATOR LIGHTS AND AC FUSE

- A red "PWR ON" LED indicator shows the presence of the + 5Vdc drive logic power supply, thereby indicating that the 3180-PI is energized.
- A red "TEMP" LED indicator shows a drive over-temperature condition. During this condition, the power is removed from the motor windings so that no holding torque is being applied. Recovery from this condition necessitates removing and then re-applying the AC power source.
- The unit's AC input is internally fused. A blown AC input fuse will prevent the power supply from energizing any of its outputs, hence, the unit will not operate. Usually, the only reason this fuse will open ("blow") is if an internal failure occurs. If an open fuse occurs, return the unit to the factory for service. **DO NOT REPLACE THE FUSE OR THE UNIT MAY BE FURTHER DAMAGED.**

SECTION 2: MOUNTING, CONNECTIONS AND PIN ASSIGNMENTS

2.1 MOUNTING

The 3180-PI is mounted by affixing its enclosure to a flat surface in one of two possible configurations. Figure 2.1 shows the mounting hole locations and diameters. It is important to leave at least two inches (51mm) of space between the drive's top, bottom, and sides to allow proper airflow for cooling.





Figure 2.1: Mounting Diagram

The heat sink should always be mounted with the fins oriented vertically, or proper cooling will not occur. Air flow should not be obstructed.

2.2 MOTOR CONNECTIONS


2.2.1 Connections Using LF or FF Type Motors (With Leads) and Superior Electric B215801-001, -002 or -003 Cables



3180 DRIVE / B215801-001, -002, or -003 CABLE / TYPE FF or LF MOTOR

Figure 2.2.1

2.2.2 Connections Using FF Type Motors (With Terminal Boxes) and Superior Electric B215801-001, -002 or -003 Cables




3180 DRIVE / B215801-001, -002, or -003 CABLE / TYPE FF (With Term. Box) MOTOR

Figure 2.2.2

2.2 MOTOR CONNECTIONS

All motor Connections are made via the 8-pin circular AMP connector. Figure 2.2 shows the possible motor wiring configurations. The diagrams in Figures 2.2.1 through 2.2.6 show the connections for each combination of cable and motor type.



4-LEAD MOTORS, SERIES CONNECTION

Figure 2.2: Motor Connections

J2: Motor Connections


Cabling: Shielded, twisted-pair cable is highly recommended. Twist together the wires for each motor phase; six twists per foot (305mm) is a good guideline.

Superior Electric Motor cables are available as follows:

Length	(Unterminated Leads On Motor End) Part Number	(Plug on Motor End)* Part Number
10 ft. (3m)	B215801-001	B216066-001
25 ft. (7.6m)	B215801-002	B216066-002
50 ft. (15.2m)	B215801-003	B216066-003

*Mates with receptacle on M062, M062 and M063 motors that have receptacles (M061-CS08, etc.).


2.2.3 Connections Using CF Type Motors (With Connectors) and Superior Electric B216066-001, -002 or -003 Cables



3180 DRIVE / B216066-001, -002, or -003 CABLE / TYPE CF MOTOR

Figure 2.2.3


2.2.4 Connections Using LF or FF Type Motors (With Leads) and Customer Supplied Cables



3180 DRIVE / CUSTOMER SUPPLIED CABLE / TYPE FF or LF MOTOR

Figure 2.2.4

2.2.5 Connections Using FF Type Motors (With Terminal Boxes) and Customer Supplied Cables



3180 DRIVE / CUSTOMER SUPPLIED CABLE / TYPE FF (With Term. Box) MOTOR

Figure 2.2.5

2.2.6 Connections Using CF Type Motors (With Connectors) and Customer Supplied Cable




Figure 2.2.6

2.3 CONNECTION DIAGRAMS

2.3.1 J1: DO NOT USE (15-pin "D" type)

2.3.2 J2: Motor (see 3.5.2.1 for pin assignments)

2.3.3 J3: Power Input (see 3.5.1.2 for terminal assignments)

2.3.4 J4: Parallel I/O Connections (25 pin. "D" type) (see 3.6.1 for pin assignments)

2.3.5 J5: Serial I/O (9-pin, "D" type) (see 3.6.2 for pin assignments)




Figure 2.3 3180-PI Connections

2.4 SERIAL COMMUNICATION CONNECTION DIAGRAMS

2.4.1 Single Indexer System

In a single indexer system, it is necessary to activate the Indexer by initially transmitting the device attention character and its corresponding device address. A new Indexer has a device address of 1. See Figure 2.4 for wiring instructions.




Figure 2.4 Single Indexer Connections

2.4.2 Multiple Indexer System

In a multiple indexer system, up to 99 indexers may be daisy-chained together. Daisy-chaining is a method in which multiple indexers can communicate with a single host using only 1 serial port. In order to daisy chain multiple indexers together, each indexer must first be programmed with a unique device address. The device address can

be any number 1 through 99, as long as each indexer has a unique number. The device addresses need not to be consecutive; the indexers can be placed in the chain in any position regardless of their device addresses. The device address of zero is used to communicate to all indexers simultaneously. See Figure 2.5 for wiring instructions.




FIGURE 2.5 Daisy-Chain Connections

2.5 Memory Protect Switch

All Micro Series Indexers incorporate a hardware Memory Protect Switch to help prevent accidental or intentional program or parameter changes. When the switch is in the “**Protect**” position, changes to the program or to the parameters will not be allowed. Such changes can be made by placing the switch in the “**Write**” position.

An Indexer which has the Memory Protect Switch also has a metal grounding strap which connects the 9-pin and the 25-pin filter type “D” connectors. Located midway between the two connectors is a hole to allow access to the Memory Protect Switch (see Figure 2.3).

When the Memory Protect Switch is positioned toward the 25-pin connector, the Indexer is in the “**Write**” mode. It is in the “**Protect**” mode when the switch is positioned toward the 9-pin connector. The switch is in the “**Write**” mode when the Indexer is shipped from the factory.

In all but the most severe applications, it will not be necessary to use the Memory Protect Switch. However, some users may wish to use the protect feature to prevent unauthorized access to the Indexer program or parameters.

SECTION 3: SPECIFICATIONS

3.1 DRIVE DESCRIPTION

- Bipolar, speed adjustable, 2-phase, line operated chopper drive with integral translator and indexer.
- Full, half, 1/10, or 1/125 step (Step resolution dependent on model type).
- Power semiconductor type: N-channel FET
- Chopping frequency: 20 KHz.
- Control signals are optically isolated from the motor drive circuit.

3.2 DRIVE PERFORMANCE

Resolution: Half-step or full-step (3180-PI)
1/10 microstep (3180-PI10)
1/125 microstep (3180-PI125)

Step Rate: 0 to 10,000 full-steps/sec. (3180-PI)
0 to 20,000 half-steps/sec. (3180-PI)
0 to 100,000 1/10 microsteps/sec (3180-PI10)
0 to 1,250,000 1/125 microsteps/sec. (3180-PI125)

Speed/torque: See Section 6 for typical Speed/Torque Curves.

3.3 MOTOR COMPATIBILITY

3180-PI

Motor Types: Superior Electric motors are recommended
Frame Sizes: 61mm to 112mm
No. of Leads: 4
Min. Inductance: 8.0 mH
Max. Inductance: 64 mH
Voltage to Motor: 170-190 Volts
Max. motor cable length: 100 feet (30.5 meters)

MOTORS FOR USE WITH 3180-PI

SECO Type Number	3180 CURRENT SETTING (AMPERES)*
M061-CF408 }	0.5
M061-LF408 }	
M062-CF402 }	1.0
M062-LF402 }	
M063-CF401 }	1.0
M063-LF401 }	
M091-FF401	1.0
M092-FF402	2.0
M093-FF402	3.0
M111-FF401	3.0
MX111-FF401	3.0
M112-FF401	3.0
MH112-FJ4201	3.0

* Use this number to set the drive's "nominal" current as described in Section 3.8.

3.4 DRIVE MECHANICAL SPECIFICATIONS

Size
(inches): 6.29L x 5.67W x 7.69H (Height over connectors, excluding mounting flanges. Height with flanges is 8.0 inches)
(mm): 159.7L x 144.0W x 195.3H
Weight: 3180-PI: 7(lbs.) 3.2(kg)

3.5 ELECTRICAL SPECIFICATIONS

3.5.1 AC Input

3.5.1.1 Power and Voltages

AC input Range: 102-132 Vac. 50/60Hz
Fuse Rating: 125 volts, 5 amps, Type 2AG (Littelfuse type 225005)
Drive power dissipation (worst case)
3180-PI: 90 watts

3.5.1.2 AC Input Connections

J3: 3-pin Screw terminal strip

Pin	Assignment
"H"	Hot (black)
"C"	Common or Neutral (white)
"G"	Ground (green)

3.5.2 OUTPUT TO MOTOR

3.5.2.1 Motor Connections

J2: 8-pin twist-lock circular female Amp connection

Pin	Assignment	Pin	Assignment
1	M3	5	No connection
2	M5	6	M1
3	No connection	7	No connections
4	Ground	8	M4

NOTE: Motor phase A is M1 and M3, and phase B is M4 and M5.

Mates to male connector, AMP part number 206434-1 (AMP pin part number 66506-8 and AMP clamp part number 206062-1).

3.6 MICRO-SERIES INDEXER I/O SIGNALS INTERFACES

3.6.1 Parallel I/O

J4: 25-pin, "D" Type Connector, female

Pin	Assignment	Pin	Assignment
1	Vo SIGNAL COMMON	14	Vo SIGNAL COMMON
2	D7 INPUT	15	D6 INPUT
3	D5 INPUT	16	D4 INPUT
4	D3 INPUT	17	D2 INPUT
5	D1 INPUT	18	D0 INPUT
6	MOTION BUSY*	19	NOT USED
7	STROBE 7	20	STROBE 6
8	STROBE 5	21	STROBE 4
9	STROBE 3	22	STROBE 2
10	STROBE 1	23	STROBE 0
11	OUTPUT 2*	24	OUTPUT 1*
12	ALL WINDINGS OFF OUT*	25	PULSE OUTPUT*†
13	CW/CCW OUT*		

*These outputs are open collectors. If monitored, they must be pulled up to an external voltage source (maximum 24 Vdc) through a series resistor to limit the sink current to a maximum of 40 millamps.

*The strobe outputs are also open collector; if they are connected directly to the indexer's inputs, then pull-up resistors are not required.

† Signal line filtering has been incorporated to help keep electrical interference from affecting Indexer operation. Because of this, it is not possible to use the Pulse Output signal (pin 25 on the 25-pin "D" connector) when operating in the 1/125 microstep mode. The pulse output on this pin is not affected when operating in the full-step, half-step or 1/10 microstep modes. A maximum pull-up impedance of 3.9k ohms should be used when utilizing the Pulse Output.

† Note that the Indexer can still operate in the 1/125 microstep mode. This limitation only affects connection to external drives via the 25-pin connector.

For maximum noise immunity, it is recommended that a twisted, shielded cable of a maximum length of 20 feet (6.1m) be used.

600A
IF
24VDC

3.6.1.1 Parallel Output Characteristics

The following pertain to: Output 1 (Pin 24), Output 2 (Pin 11), AWO Out (Pin 12), CW/CCW Out (Pin 13), PULSE Out (Pin 25) Motion Busy (Pin 6) and Strobe 0 through Strobe 7 Outputs:

- High level output: +24 Vdc max., open collector
- High level leakage current: 250 microamps max.
- Low level output: +0.4 Vdc @ 16 mA sink current
+0.7 Vdc @ 40 mA sink current

3.6.1.2 Parallel Input characteristics

The following pertain to D0 through D7 inputs:

- High level (inactive voltage): +8.5 Vdc min.; + 15 Vdc max.
- High level current: 1 milliamp maximum leakage
- Low level (active) voltage: 0.0 Vdc min.; + 6.5 Vdc max.
- Low Level current: 3.5 milliamp max.

3.6.2 Serial I/O

J5: 9-Pin "D" Type Connector, female

<u>Pin</u>	<u>Assignment</u>
1	V _o
2	RS-232 CHAIN OUT
3	RS-232 RECEIVE DATA
4	V _o
5	V _o
6	RS-232 ECHO
7	RS-232 CHAIN IN
8	+ 5 Vdc
9	+ 5 Vdc

Wire size: 24 AWG minimum. Cable with shielded, twisted pairs is highly recommended.

Run length: 50 feet (15.2m) max.

Cables available from Superior Electric:

(25-pin "D" connector on one end, 9-pin "D" connector on other)

<u>Length</u>	<u>Part No.</u>
5 ft. (1.5m)	B216059-001
10 ft. (3m)	B216059-002

3.7 ENVIRONMENTAL SPECIFICATIONS

- Operating Temp.: + 32°F to + 122°F (0°C to +50°C) Free Air Ambient
- Storage Temp.: - 40°F to + 167°F (- 40°C to +75°C)
- Humidity: 95% max., noncondensing
- Altitude: 10,000 feet (3048 meters) max.
- Cooling: Will operate up to 122 degrees F (50 degrees C) so long as maximum heat sink temperature of 176 degrees F (80 degrees C) is maintained; forced-air (fan) cooling may be required).

3.8 CURRENT SETTINGS

The current applied per motor phase is switch-selectable by a "DIP" switch accessible through an opening on the side of the indexer-drive (see figure 3.1).

NOTE: Before making this adjustment, be sure to disconnect the drive's 120 volt AC power source and wait 10 minutes for the power supply capacitors to discharge. Set the switch as follows for the appropriate current, based on the motor's rating:

NOMINAL	CURRENT (AMPS)		SWITCH POSITION			
	REDUCE	BOOST	S1	S2	S3	S4
2.0	1.0	3.0	OFF	OFF	OFF	OFF
1.5	0.75	2.25	ON	OFF	OFF	OFF
1.0	0.5	1.5	OFF	ON	OFF	OFF
0.5	0.25	0.75	OFF	OFF	ON	OFF
3.0	1.5	3.0	OFF	OFF	OFF	ON

Boost and Reduce functions are software controlled via the appropriate indexer G codes. The Boost function is useful for providing additional motor torque during acceleration; this increases current per phase by 50%, up to a maximum of 3 amperes. If desired, current may be decreased by 50% using the Reduce function. This allows for cooler motor operation at standstill in cases where the resulting lower holding torque can be accommodated.




FIGURE 3.1 Current Setting Dip Switch For 3180 Series Drive

SECTION 4: PROGRAMMING GUIDE

This section contains the information necessary to set up, enter, and edit programs and also to execute programs with the Micro Series Indexer.

By carefully reading this section through in its entirety, the user will fully understand the wide range of applications possible with the Micro Series Indexer.

4.1 OVERVIEW AND SET-UP

EIA (Electronic Industries Association) Standard RS274-D is the programming guide for numerically controlled machines. Superior Electric has utilized this standard to form the basis for the Micro Series Indexer's command structure. It was not technically desirable to conform to the standard in complete detail, but it proved beneficial in the program structure to perform complex and varied operations with a simple format. Using straightforward programming formats, the Micro Series Indexer enables the user to program and execute in either parallel (switch panel) or serial (remote terminal or host computer) communication modes.

In general, all parameters and commands can be broadly grouped into four categories, which correspond to these code groupings:

- | | |
|------------|------------------------|
| 1. L Codes | 3. N, G, X and F Codes |
| 2. H Codes | 4. Immediate Codes |

1. "**L Codes**" (discussed in Section 4.3) are used to set parameters for each indexer. These commands are not considered part of an indexer program, that is, they are made prior to any motion programming and do not have program line numbers.

It is important to remember that the **L codes are used exclusively to set the initial parameters** of a particular indexer and should not be thought of as part of the program option for the indexer.

2. "**H Codes**" (Section 4.4) are used to set indexer modes, control manual and program execution and to transmit parameters and indexer status via the serial communications port.

H codes are not part of the programming commands for the indexer. There are no program line numbers associated with the "H" codes and they are not considered to be part of the programming function.

3. "**N, G, X and F Codes**" (Section 4.5) are the programming commands for the indexer. Up to 400 lines of program instructions can be stored as a unique motion control program.

Each program is in a fixed format, and is composed of a line number, a "G" code, an "X" code and an "F" field.

A line of program has this format:

N[nnn] G[nn] X[snnnnnnn] F[nnnnnnn]

A space is used to separate the codes.

Not all codes need be programmed for each program line.

The G, X and F codes may be programmed in any order.

NOTE: The brackets, [], are used in this manual for clarity and are not to be used when entering data or variables

4. **Immediate Codes** (Section 4.2) are executed immediately upon receipt and are **not stored as part of the program**. All commands are highlighted in **bold face** for easy reference.

4.1.2 General Programming Comments

IMPORTANT PROGRAMMING NOTES

1. The indexer contains a 40 character serial buffer to accept all data and programming entries. If a **COMMAND TERMINATOR (CARRIAGE RETURN and/or LINE FEED)** is not received by the 40th character, the buffer contents are dumped and that 40 character string is lost.

Upon receipt of a CR and/or LF, an **XOFF (ASCII Code 19)** character is transmitted to the host; no further data transmission from the host should occur. However, any characters transmitted subsequent to XOFF will be stored in the buffer until the buffer capacity is reached. If the capacity is exceeded, the buffer contents are dumped.

The receipt of a **COMMAND TERMINATOR** character will cause the commands in the buffer to be executed sequentially. That is, the first command that was entered will be the first command executed. The **COMMAND DELIMITER** for a series of commands is a space. Once all the commands in the buffer have been executed, the indexer will send an **XON (ASCII Code 17)** character and will be ready to receive further data.

2. Whether the indexer is being operated from a switch panel, remote terminal or host computer, the first task that faces an operator, after all circuit connections have been made, is that of setting "L: codes", the parameters of each indexer.

3. In the following descriptions, it is important to note the **factory default values** for each parameter as entry steps can be eliminated. Upon receipt of a new indexer, the default values will have been entered for the parameters.

4. Motor speeds and acceleration will depend on the TRANSLATOR RESOLUTION setting (**L70 nnn**). Set this parameter first and then work in ascending numerical order starting with the **L06** parameter.

NOTE: If the L70 value is changed, the values for L09, L11, L12, L14 and the "F" field values must be reentered.

5. Entry of invalid data for a parameter or program field will result in the previous data being left intact.


6. If the number of characters entered exceeds the number of required characters, the data is truncated to the maximum field length for the entry.

Xon/Xoff Protocol:

The Xoff character is transmitted to the host when a CR or LF is received. The Indexer will process the information it has received and will transmit an Xon character when it is ready to accept more information from the host. The Indexer should be polled to determine when it is ready to accept more information. If **L26 3** is selected, the Indexer will transmit an "=" if it is ready to accept more information. If an Xoff character has been transmitted to the host and the command received by the Indexer calls for motion or program execution, the Indexer will send an Xon to the host. This allows the host to send any of the immediate commands such as "*" (Clear), "\$" (Feed Hold) or "#" (Cycle Stop). The host should not send "normal" commands until the Indexer is ready to accept more information. The Indexer will be ready to accept more information when motion is stopped, program is stopped and all previous commands have been executed.

4.1.3 Programming Chart For Indexer Communications - "On The Fly" Commands

"On The Fly" commands can be sent to the indexer when it is "BUSY" (When motion or program execution is active or when previously transmitted commands are being processed)."On The Fly" commands allow the indexer to send status or position information to the host. The sequence for sending "On The Fly" commands is shown below. The host must send an "On The Fly" command, followed immediately by a carriage return (CR) and/or Line Feed (LF). If the command is not sent in this manner, it will not be treated as an "On The Fly" command. Instead, it will be placed in the buffer and executed when the indexer is no longer "BUSY".



The following commands can be sent the Indexer while it is "BUSY":

- H15crlf Transmit Present Program Line Number
- H17crlf Transmit Present Absolute Position
- H18crlf Transmit Mode Status
- H19crlf Transmit Motion Status
- H20crlf Transmit I/O Status

Any other commands sent to the Indexer will be executed when the Indexer is no longer "BUSY".

P.C. PROGRAM FLOWCHART FOR INDEXER COMMUNICATIONS




Figure 4.1, Program Flow Chart For Indexer Communications

4.2 IMMEDIATE COMMANDS

* CLEAR (ASCII Code 42)

This command IMMEDIATELY halts all motor motion and program execution and will cause a loss of home position. The program line pointer is reset to the line number specified with the **L41** parameter.

The RS232 input buffer is also cleared and the indexer transmits an XOFF and then an XON when a CLEAR command is used.

\$ FEEDHOLD (ASCII CODE 36)

This command will immediately bring current motor motion to a controlled stop with deceleration determined by the **L11** parameter (ACCELERATION/DECELERATION).

Motion can be continued without loss of position by using a **H01** CYCLE START command if the feedhold was applied during program execution. If a feedhold was applied during a **H08** (return to electrical home) command, a subsequent **H08** will continue the motion. A feedhold during a **H10** (return to mechanical home) command requires a **H10** to continue the motion. The line number cannot be altered during a feedhold as the remaining move distance needs to be completed. A CLEAR (*) can be issued if it is not desired to complete the motion.

<nn DEVICE ATTENTION CHARACTER

If <[nn] = 00, all indexers will be addressed; otherwise, the indexer with the value set by the **L21** parameter that matches the <[nn] value will become the active indexer. The indexer will respond with “=XON” when the <[nn] value matches the value set with the **L21** parameter and the indexer is ready for commands. If the indexer is not ready, the indexer responds with “:”. If <00 is used, there is no indexer response.

CYCLE STOP (ASCII Code 35)

This command halts program execution after the current program line is completed.

This command is used to stop programs executing with **L06 [2]** or **L06 [3]** EXECUTION FORMAT settings.

^H (CONTROL H) BACKSPACE AND DELETE (ASCII Code 8)

The CONTROL H (^H) command will cause a backspace and delete one character on the current program line. The ^H command is executed immediately upon entry and is not stored as part of the program.

^X (CONTROL X) DELETE LINE (ASCII Code 24)

The CONTROL X (^X) command will delete the program line that has been entered in the line buffer.

This command must be used prior to a COMMAND TERMINATOR.

The ^X command is executed immediately upon entry and is not stored as part of the program.

4.3 L Codes: INDEXER PARAMETERS

L codes are used to set parameters for each indexer. These parameters affect the entire operation of the indexer and cannot be changed during program execution; therefore, they should be programmed first. The L codes can be categorized into three areas of interest: motion, execution and serial communication parameters.

Motion parameters: L08, L09, L11, L12, L14, L17, L18, L19, L70

Execution parameters: L06, L07, L41, L44, L45, L48, L49

Communication parameters: L21, L22, L23, L25, L26

The L codes have been preset at the factory to default values; these are listed as “Factory Default” settings.

INDEXER PARAMETER FACTORY DEFAULT VALUES

Full Step Translator	1/10 Step Translator	1/125 Step Translator
L06 = 1	L06 = 1	L06 = 1
L07 = 0100	L07 = 0100	L07 = 0100
L08 = +	L08 = +	L08 = +
L09 = 0001000	L09 = 0010000	L09 = 0125000
L11 = 0002500	L11 = 0025000	L11 = 0312500
L12 = 0000250	L12 = 0002500	L12 = 0031250
L14 = 0001000	L14 = 0010000	L14 = 0125000
L17 = +00000000	L17 = +00000000	L17 = +00000000
L18 = -00000000	L18 = -00000000	L18 = -00000000
L19 = +00000000	L19 = +00000000	L19 = +00000000
L21 = 01	L21 = 01	L21 = 01
L22 = 9600	L22 = 9600	L22 = 9600
L23 = 8	L23 = 8	L23 = 8
L25 = 1	L25 = 1	L25 = 1
L26 = 0	L26 = 0	L26 = 0
L41 = 000	L41 = 000	L41 = 000
L44 = 0050	L44 = 0050	L44 = 0050
L45 = 0	L45 = 0	L45 = 0
L48 = 000	L48 = 000	L48 = 000
L49 = 00	L49 = 00	L49 = 00
L70 = 001	L70 = 010	L70 = 125

L06 [n] PROGRAM EXECUTION FORMAT

This command determines the fashion in which a program will be executed after a CYCLE START (**H01**) command is issued. The options are:

[n] = 1 Single-line program execution format

When a CYCLE START command is given, the current program line is executed. The line pointer is then incremented to the next program line and the cycle stops. The program line pointer may be moved to another line by using the N [nnn] command.

Another CYCLE START (**H01**) command will repeat the process.

[n] = 2 Automatic program execution format

In this mode, a CYCLE START command will cause the program to execute from the present program line to line number 400 or to a line command that contains a **G30** that is not a part of a **G11** (subroutine call) command. The program will then halt execution and the program line pointer will be set to the line number specified with the **L41** parameter. A second CYCLE START command will cause the program to start execution from this line number.

[n] = 3 Continuous program execution format

In this mode, a CYCLE START command will cause the program to execute from the present program line to line number 400 or to a line command that contains a **G30** that is not part of a **G11** (subroutine call) command. The program line pointer is then set to the line number specified with the **L41** parameter and program execution continues until a # CYCLE STOP command or a * CLEAR command is issued.

Example: **L06 2** CRLF sets automatic program execution format. [CRLF = carriage return, line feed].

Factory default: **L06 1**

NOTES: When line 00 (MDI line) is executed, the execution format is ignored as line 00 executes one time for each CYCLE START and the line pointer remains at line 00.

This command is transparent when using the SSP-500. The mode is changed when using specific displays. Refer to the SSP-500 manual for details.

L07 [nnnn] STROBE DELAY TIME

This sets the length of time, in milliseconds, that the output strobe line will be ACTIVE (low) before the connected data line is read.

The delay range is 0 milliseconds to 9999 milliseconds.

See Section 5 for an explanation of the STROBE and DATA functions.

Factory default L07: [nnnn] = 100 milliseconds

Strobe delay accuracy is $\pm 2.5\%$ of the selected value.

Example: L07 1000 CRLF sets a 1000 millisecond strobe delay.

L08 [s] MECHANICAL HOME DIRECTION

Sets the direction that the motor will turn when a **H10 or G78** RETURN TO MECHANICAL HOME command is issued.

A "+" will cause the motor to turn clockwise.

A "-" will cause the motor to turn counterclockwise.

Factory default **L08**: s = +.

Example: **L08 +** CRLF sets a clockwise mechanical home direction.

L09 [nnnnnnn] JOG SPEED

Sets the desired speed, in pulses/second, to be used when the motor is run in the JOG mode and the HIGH SPEED mode.

Allowable values for this parameter are:

full step	(L70 = 1)	0 to 115,000 pulses/sec.
half step	(L70 = 2)	0 to 115,000 pulses/sec.
1/5 step	(L70 = 5)	0 to 115,000 pulses/sec.
1/10 step	(L70 = 10)	0 to 115,000 pulses/sec.
1/125 step	(L70 = 125)	0 to 1,875,000 pulses/sec.

Factory default:

full step	(L70 = 1)	1,000 pulses/sec.
half step	(L70 = 2)	2,000 pulses/sec.
1/5 step	(L70 = 5)	5,000 pulses/sec.
1/10 step	(L70 = 10)	10,000 pulses/sec.
1/125 step	(L70 = 125)	125,000 pulses/sec.

Example: **L09 1200** CRLF sets a jog speed of 1200 pulses/sec.

PLEASE NOTE: The range of values that will be accepted by the **L09, L11, L12** and **L14** parameters is set by the **L70 TRANS-LATOR RESOLUTION** value.

If **L70** is set or changed after setting the **L09, L11, L12 or L14** parameters, the range may not be valid and *incorrect motion may occur*.

ALWAYS SET THE L70 PARAMETER FIRST.

L11 [nnnnnnn] ACCELERATION/DECELERATION

Sets the value, in pulses/sec/sec, for acceleration and deceleration. The same rate applies to both.

Whenever the indexer initiates motion, it is always at the speed set with the **L12 LOW SPEED** parameter. This is the instantaneous starting speed of a motor; it will then ramp up to the JOG or HOME SPEED value or the FEED RATE using the acceleration rate set with the **L11 ACCELERATION/DECELERATION** parameter.

When the motor is running at JOG SPEED and a feedhold is asked for, the motor will decelerate from JOG SPEED using the deceleration rate set with the **L11** parameter and will then stop.

When a move distance and feed rate have been programmed, the motor will decelerate to a stop at the end of the move using the deceleration rate set with the **L11** parameter.

The ranges for ACCELERATION/DECELERATION are:

[nnnnnnn] = 25 to 9,999,999 pulses/sec/sec.

Factory defaults:

full step	(L70 = 1)	2,500 pulses/sec/sec
half step	(L70 = 2)	5,000 pulses/sec/sec
1/5 step	(L70 = 5)	12,500 pulses/sec/sec
1/10 step	(L70 = 10)	25,000 pulses/sec/sec
1/125 step	(L70 = 125)	312,500 pulses/sec/sec

Example: L11 5000 CRLF sets an acceleration/deceleration rate of 5000 pulses/second/second.

L12 [nnnnnnn] LOW SPEED

This command sets the speed at which the motor will run if the **H05 LOW SPEED MODE** command is used, or the speed at which the motor will start before accelerating to the HIGH SPEED value.

The ranges for LOW SPEED are:

full step	(L70 = 1)	0 to 115,000 pulses/sec.
half step	(L70 = 2)	0 to 115,000 pulses/sec.
1/5 step	(L70 = 5)	0 to 115,000 pulses/sec.
1/10 step	(L70 = 10)	0 to 115,000 pulses/sec.
1/125 step	(L70 = 125)	0 to 1,875,000 pulses/sec

Factory defaults:

full step	(L70 = 1)	250 pulses/sec.
half step	(L70 = 2)	500 pulses/sec.
1/5 step	(L70 = 5)	1,250 pulses/sec.
1/10 step	(L70 = 10)	2,500 pulses/sec.
1/125 step	(L70 = 125)	31,250 pulses/sec.

Example: L12 300 CRLF sets a low speed of 300 pulses/sec.

L14 [nnnnnnn] HOME SPEED

This command sets the speed, in pulses/second, with which the motor will return home when a **H10 or G78 RETURN TO MECHANICAL HOME**, or a **H08 or G76 RETURN TO ELECTRICAL HOME** command is executed.

The ranges for the HOME SPEED are:

full step	(L70 = 1)	0 to 115,000 pulses/sec.
half step	(L70 = 2)	0 to 115,000 pulses/sec.
1/5 step	(L70 = 5)	0 to 115,000 pulses/sec.
1/10 step	(L70 = 10)	0 to 115,000 pulses/sec.
1/125 step	(L70 = 125)	0 to 1,875,000 pulses/sec.

Factory default:

full step	(L70 = 1)	1,000 pulses/sec.
half step	(L70 = 2)	2,000 pulses/sec.
1/5 step	(L70 = 5)	5,000 pulses/sec.
1/10 step	(L70 = 10)	10,000 pulses/sec.
1/125 step	(L70 = 125)	125,000 pulses/sec.

Example: L14 2000 CRLF sets a home speed of 2000 pulses/second.

L17 [snnnnnnn] OFFSET DIRECTION AND DISTANCE FROM ELECTRICAL HOME

This command sets the direction and distance, in pulses, that the motor will automatically move after a **H10 or G78 RETURN TO MECHANICAL HOME** command has been issued and the motor has returned to the HOME LIMIT switch.

See Section 5.2.3 on hardware inputs for a description of the HOME LIMIT switch function.

[s] = + or -

[nnnnnnnn] = 0 to 99,999,999 pulses.

Factory default L17: [s] = +: [nnnnnnnn] pulses = 0.

Example: L17 - 1000 CRLF sets an offset of 1000 pulses in the negative direction.

L18 [snnnnnnn] CLOCKWISE SOFTWARE TRAVEL LIMIT

s = + to enable the feature

s = - to disable the feature

[nnnnnnnn] = 0 to 99,999,999 pulses

When enabled, motion in the clockwise direction that causes the absolute position to exceed the **L18** value will result in a feedhold being activated. Only motion in the opposite direction is permitted.

Factory default L18: [s] = -[nnnnnnnn] = 0 pulses

Example: L18 +5000 CRLF will enact a feedhold should the absolute position exceed +5000 and no further clockwise motion is permitted.

L19 [nnnnnnnn] COUNTERCLOCKWISE SOFTWARE TRAVEL LIMIT

s = - to enable the feature
s = + to disable the feature
[nnnnnnnn] = 0 to 99,999,999 pulses

When enabled, motion in the counterclockwise direction that causes the absolute position to exceed the **L19** value will result in a feedhold being activated. Only motion in the opposite direction is permitted.

Factory default **L19**: [s] = + [nnnnnnnn] = 0 pulses

Example: **L19** -7500 CRLF will enact a feedhold should the absolute position exceed -7500 and no further counterclockwise motion is permitted.

L21 [nn] ASSIGN DEVICE IDENTIFICATION NUMBER

This will assign a unique device number to each indexer in situations where multiple indexers (up to 99 are permitted) have been daisy-chained.

This number will be used with the <[nn] DEVICE ATTENTION command to activate a particular indexer.

The range for **L21** is 01 to 99
Factory default **L21**: [nn] = 01

Example: **L21** 05 CRLF sets an identification number of 5.

L22 [nnnn] BAUD RATE

This command sets the serial port data transfer rate in bits/second (baud).

The acceptable values for [nnnn] are:
[nnnn] = 300, 1200, 2400 and 9600
Factory default **L22**: [nnnn] = 9600

NOTE: Most of the recently manufactured terminals and desktop computers are set at 9600 baud. If the computer or terminal used is not 9600 baud, it will not be able to communicate with a new indexer. A nondefault rate will have to be set either with a compatible switch or with a switch panel as described in Section 5.

L23 [n] CHARACTER LENGTH

This sets the number of data bits in a character sent via serial communications.

The acceptable values for [n] are: [n] = 7 or 8.
Factory default **L23**: [n] = 8

L25 [n] PARITY

This setting determines whether parity applies to serial communication commands and, if parity is selected, whether odd or even parity is applied. The acceptable values for [nn] are:

- [n] = 1 Parity disabled
- [n] = 2 Parity enabled, odd parity
- [n] = 3 Parity enabled, even parity

Factory default **L25**: [n] = 1, Parity disabled.

NOTE: When parity is disabled, two stop bits will be sent, regardless of the character length. When odd or even parity is set, one stop bit will be sent if L23 CHARACTER LENGTH is set to [n] = 8. Two stop bits will be sent if L23 is set to [n] = 7.

L26 [n] ACKNOWLEDGE

This parameter selects the transmission protocol which the Indexer will use when responding to input commands. If the command **L26** n is issued while the Indexer is busy, the command will be processed when the Indexer is no longer busy.

Range: 0 to 7

Factory Default **L26**: [n] = 0

n Transmission Mode Selected	Xon/Xoff Protocol Enabled
0 Normal Transmission Mode (No "EOT" or "=" characters)	
1 "EOT" follows each complete data transmission to the host	
2 "=" is transmitted when Indexer is ready for more commands	
3 "EOT" follows each complete data transmission to the host and "=" is transmitted when the Indexer is ready for more information	
n Transmission Mode Selected	Xon/Xoff Protocol Disabled
4 Normal Transmission Mode (No "EOT" or "=" characters)	
5 "EOT" follows each complete data transmission to the host	
6 "=" is transmitted when Indexer is ready for more commands	
7 "EOT" follows each complete data transmission to the host and "=" is transmitted when the Indexer is ready for more information	

Xon character is ASCII code 17

Xoff character is ASCII code 19

EOT character is ASCII code 04

Xon/Xoff Protocol:

The Xoff character is transmitted to the host when a CR or LF is received. The Indexer will process the information it has received and will transmit an Xon character when it is ready to accept more information from the host. The Indexer should be polled to determine when it is ready to accept more information. If **L26** 3 is selected, the Indexer will transmit an "=" if it is ready to accept more information. If an Xoff character has been transmitted to the host and the command received by the Indexer calls for motion or program execution, the Indexer will send an Xon to the host. This allows the host to send any of the immediate commands such as "*" (Clear), "\$" (Feed Hold) or "#" (Cycle Stop). The host should not send "normal" commands until the Indexer is ready to accept more information. The Indexer will be ready to accept more information when motion is stopped, program is stopped and all previous commands have been executed.

L41 [nnn] AUTO START LINE NUMBER

This parameter determines the line number to which the program line pointer will automatically be set upon powerup, during invalid program execution, upon encountering a **G30** command that is not part of a **G11** subroutine call or after a clear command (*) has been executed.

The acceptable values for [nnn] = 0 to 400.

Factory default **L41**: [nnn] = 0

Example: **L41 200 CRLF** sets the autostart line number to 200.

L44 [nnnn] PROGRAM LINE DELAY

During program execution, a delay of **L44** parameter length in milliseconds will occur after each line completes executing. This delay should be set to allow sufficient motor settling time. The delay is also invoked after **G76** or **G78** execution.

The acceptable values for [nnnn] = 0 to 9999 milliseconds.

Factory default **L44**: [nnnn] = 50 milliseconds.

Example: **L44 250 CRLF** sets a delay of 250 milliseconds after execution of each line.

L45 [n] LIMIT SWITCH ENABLE

The user can utilize the inputs labeled CW LIMIT- and CCW LIMIT- either as limit switches (**L45 0**) or as additional programmable inputs (**L45 1**).

[n] = 0 to enable limit switch operation

[n] = 1 to disable limit switch operation for utilization as additional programmable inputs.

Factory default **L45**: [n] = 0

Example: **L45 1 CRLF** disables limit switch operation as the two limit switch inputs are used as additional programmable inputs.

Note: When [n] = 1, the CW LIMIT- input becomes input 3 and the CCW LIMIT- input become input 4.

L48 [nnn] PROGRAM LINE TRANSFER COUNT

Used in conjunction with the **H12** and **H14** commands, **L48** contains the number of lines the command is to act upon. If **L48** contains 0, lines 1 through 400 will be cleared (**H12**) or transferred (**H14**). Otherwise, the command is effective for the number of lines indicated by the **L48** value starting from the present line number.

Factory default **L48**: [nnn] = 000

Example: **L48 10 CRLF** sets a 10 line execution block for **H12** and **H14** commands.

NOTE: L48 MUST BE SET WITH 0 TO OPERATE WITH AN SSP-500.

L49 [nn] PARAMETER TRANSFER DESIGNATION

Used in conjunction with the **H16** command, **L49** contains the designated parameter to transfer. If **L49** contains 0, all parameters are transferred. Otherwise, only the parameter designated by **L49** is transferred. If **L49** contains an invalid parameter, **H16** transmits only a Carriage Return/Line Feed. This parameter IS NOT stored in nonvolatile memory.

Factory default **L49**: [nn] = 00

Example: **L49 06 CRLF** causes **H16** to transfer the contents of the **L06** parameter.

NOTE: L49 MUST BE SET WITH 0 TO OPERATE WITH AN SSP-500.

L70 [nnn] TRANSLATOR RESOLUTION

This sets the step resolution of the motor drive translator.

The acceptable values for [nnn] are:

full step	1
half step	2
* 1/5 step	5
* 1/10 step	10
* 1/125 step	125

* These settings are only valid for the 440, 3180 and 6180 Series drives.

Factory default:

full step	1
1/5 step	5
1/10 step	10
1/125 step	125

Example: **L70 2 CRLF** sets a half step translator resolution.

NOTE: For all 230 and 430 Series indexers, the L70 parameter must be set to 1 or 2 for the drive to work properly.

NOTE: Since the ranges of L09, L11, L12 and L14 depend on the setting of L70, it is important to set the L70 parameter first so that range confusion will be avoided.

4.4 H CODES: COMMANDS FOR MODES OF OPERATION

H codes perform four different functions in indexer operations:

1. They control manual and program execution. H codes, however, cannot be used as programmable instructions.
2. They are used to set MODES OF OPERATION.
3. They are used in PROGRAM EDITING to clear program data.
4. They issue transmission instructions, that is, they allow stored parameters and status data to be TRANSFERRED via the serial communications port.

The H code are categorized into the following four areas of interest.

Mode Commands: H2, H3, H4, H5, H24, H25

Execution Commands: H1, H6, H7, H8, H9, H10

Transfer Commands: H13, H14, H15, H16, H17, H18, H19, H20, H23

Edit Commands: H11, H12

For ease of reference, the H codes are presented here in numerical order.

H01 CYCLE START

This is a "GO" command. It will start program execution from the present line number based on the execution format set with **L06**.

This command will also restart motion during program execution after a \$ FEEDHOLD command.

H02 STEP MODE

This command sets the indexer in the single-step mode for manual motion operation.

NOTE: The H02 and H03 commands do not cause motion, they only set the mode in which motion will occur when it is called for.

Motion is started by issuing a H06 CLOCKWISE or a H07 COUNTERCLOCKWISE command after setting the H02 STEP or H03 JOG mode. When the H02 STEP mode command is followed by a H06 or H07 command, a single step will be made by the motor.

Upon power up of the system, the indexer is set in the STEP mode.

H03 JOG MODE

This command sets the indexer in the continuous motion mode for manual motion operation.

When a **H06 or H07** command is issued after a **H03** command, the motor will turn continuously until a \$ FEEDHOLD command is issued.

The speed at which the motor will turn is dependent on whether the HIGH SPEED or the LOW SPEED mode has been selected.

If the HIGH SPEED mode is enabled, the motor will run at the value set with the **L09** parameter. If the LOW SPEED mode is enabled, the motor will run at the value set with the **L12** parameter.

H04 HIGH SPEED MODE

This command allows the motor to run at the speed, in pulses per second, that was set with the F[x] FEEDRATE command during program execution, or at the value set with the **L09** parameter when the JOG mode is selected.

When a **H06** or a **H07** command is issued after a **H04** command, the motor will accelerate according to the value set with the **L11** parameter to the jog speed set with the **L09** value.

JOGGING is terminated with a \$ FEEDHOLD command and the motor decelerates to a stop according to the value set with the **L11** parameter.

When the indexer is powered up, it is set in the HIGH SPEED MODE.

H05 LOW SPEED MODE

This command allows the motor to run at the speed, in pulses per second, that was set with the **L12** LOW SPEED parameter. **No acceleration or deceleration is allowed.**

A **H05** command followed by a **H03** and a **H06** or **H07** command will cause the motor to JOG at the speed set with the **L12** parameter. If the LOW SPEED mode is enabled when a **H01** CYCLE START command is issued, all motion will be at the value set with the **L12** parameter. Any F field values will be ignored.

H06 TURN IN CW DIRECTION

This command will cause the motor to move in the CLOCKWISE direction.

The type of motion will depend on whether the indexer is in the STEP or JOG mode, the HIGH SPEED or LOW SPEED mode and the parameters set with the **L09**, **L11** and **L12**.

H07 TURN IN CCW DIRECTION

This command will cause the motor to turn in the COUNTERCLOCKWISE direction. The type of motion will depend on whether the indexer is in the STEP or JOG mode, the HIGH SPEED or LOW SPEED mode and the parameters set with the **L09**, **L11** and **L12**.

H08 RETURN TO ELECTRICAL HOME

Electrical home is established when the indexer is powered up or when a **H09** SET HOME command is issued. This command will cause the motor to return to the absolute position of 0 (electrical home).

In executing this motion, the motor will move in the **opposite direction** of the absolute position sign until the absolute position counter reaches 0.

H09 SET ELECTRICAL HOME

This command will set the absolute position counter to zero. This, in effect, sets the **current motor position as the electrical home position**.

H10 RETURN TO MECHANICAL HOME

This command will cause the indexer to return the motor to the MECHANICAL HOME LIMIT SWITCH.

When this command is being executed, the motor will turn in the **direction** set with the **L08** parameter and will **offset** the motor from the home limit switch the direction and distance set with the **L17** parameter, at the speed set with the **L14** parameter. When motion is completed, the motor position becomes electrical home as the absolute position counter is set to zero.

H11 CLEAR PRESENT PROGRAM LINE

This command will **delete** the contents of the program line designated by the line pointer.

USE WITH CAUTION.

Once deleted, the information contained in that program line is lost and is impossible to retrieve.

Example: **N020 H11** CRLF will delete the contents of line 20.

H12 CLEAR PROGRAM

This command, with **L48 = 0**, will clear the entire program that is stored in the indexer EEPROM.

Lines 1 through 400 will be IRRETRIEVABLY ERASED.

NOTE: After a CLEAR PROGRAM command, with **L48 = 0**, the line pointer will be returned to the value set by **L41**.

If all 400 lines are programmed, this command may take as long as 15 seconds to complete execution.

An **H12** is not allowed while in a FEEDHOLD condition

Example: **L48 5 N010 H12** CRLF results in the deletion of the contents of lines 10, 11, 12, 13 and 14.

An additional **H12** command deletes the contents of lines 15, 16, 17, 18 and 19.

H13 TRANSMIT CONTENTS OF PRESENT PROGRAM LINE

This command causes the indexer to transmit the contents of the program line at the program line pointer through the RS232 serial interface port.

H13 transfers are always in a fixed format as follows:

Nnnn Gnn X+nnnnnnnn FnnnnnnnCRLF

N is in column 1

G is in column 6 (if programmed, otherwise a space)

X is in column 10 (if programmed, otherwise a space)

F is in column 21 (if programmed, otherwise a space)

If a program line does not contain all the fields, spaces fill in the unprogrammed fields.

Example: If program line number 100 contains "**G90 X+1234 F5678**", then

N100 H13 CRLF would result in the following transmission:

N100 G90 X+00001234 F0005678CRLF

H14 TRANSMIT PROGRAM

This command, with **L48 = 0**, causes the indexer to transmit program lines 1 through 400 through the RS232 serial port.

Each program line is transmitted in the same format as **H13**.

N001 Gnn X+snnnnnnnn FnlnnnnnnCRLF

N002 Gnn X+snnnnnnnn FnlnnnnnnCRLF

" " " "

N399 Gnn X+snnnnnnnn FnlnnnnnnCRLF

N400 Gnn X+snnnnnnnn FnlnnnnnnCRLF

With **L48 = 0**, after the **H14** command is executed, the line number is reset to the value set by **L41**.

After **H14** execution during a feed hold, the line number is reset to the line number that was active during the feed hold.

Example: **L48 2 N020 H14** CRLF results in the transfer of the contents of lines 20 and 21.

N020 G90 X+00001000 F0002000CRLF
N021 G91 X+00002000 F0002500CRLF

An additional **H14** CRLF transfers the contents of line 22 and 23.

N022 G64 X+00001234 CRLF
N023 G30 CRLF

H15 TRANSMIT THE CURRENT PROGRAM LINE NUMBER

This command will transmit the current program line number. This H code can be executed while the indexer is in motion, executing a program or in parallel mode.

Example: If the line number is equal to 100, **H15** CRLF results in N100CRLF being transmitted by the indexer.

H16 TRANSIT PARAMETERS

This command, with **L49=0**, will cause the contents of the L parameters to be transmitted through the RS232 serial port in the order shown below:

NOTE: The Brackets [] are for clarity and are not transmitted.

L06 [n]CRLF
L07 [nnnn]CRLF
L08 [s]CRLF
L09 [nnnnnn]CRLF
L11 [nnnnnn]CRLF
L12 [nnnnnn]CRLF
L14 [nnnnnn]CRLF
L17 [snnnnnn]CRLF
L18 [snnnnnn]CRLF
L19 [snnnnnn]CRLF
L21 [nn]CRLF
L22 [nnnn]CRLF
L23 [n]CRLF
L25 [n]CRLF
L26 [n]CRLF
L41 [nnn]CRLF
L44 [nnnn]CRLF
L45 [n]CRLF
L48 [nnn]CRLF
L49 [nn]CRLF
L70 [nnn]CRLF

Examples

L49 70 H16 CRLF results in the transfer of the contents of parameter L70: L70 nnn CRLF is transmitted

L49 99 H16 CRLF results in no parameter transfer as L99 is nonexistent: CRLF is transmitted.

H17 TRANSMIT ABSOLUTE POSITION

This command causes the indexer to transmit the current contents of the absolute position counter through the RS232 serial interface port. This H Code can be executed while the indexer is in motion, executing a program or in the parallel mode. The data transmission format is:

snnnnnnnnn CRLF

EXAMPLE: If **H17** CRLF results in +0000001000CRLF being transmitted, the absolute position is +1000 pulses.

CAUTION: If motion is called for that exceeds the maximum absolute position (9,999,999,999 pulses), the absolute position counter will roll over (reset to 0 and continue counting). In this case, the absolute position counter would contain erroneous information.

H18 TRANSMIT MOTION STATUS

The "TRANSMIT" command will output the requested data via the RS232C serial port.

This command causes the current status of +LIMIT, -LIMIT, HOME LIMIT, CLEAR, FEED HOLD, and STOP EXECUTION data inputs. This H Code can be executed while indexer is in motion, executing a program or in parallel mode.

The data is transmitted in the following format:

00000000CRLF

n.....STOP EXEC	0=inactive	1=active
.n.....CCW DIR	0=inactive	1=active
..n.....CW DIR	0=inactive	1=active
...n....FEEDHOLD	0=inactive	1=active
....n...CLEAR	0=inactive	1=active
.....n..HOME LIMIT	0=inactive	1=active
.....n.CCW LIMIT	0=inactive	1=active
.....nCW LIMIT	0=inactive	1=active

EXAMPLE: If **H18** CRLF results in 00001001CRLF being transmitted, CW limit and clear are active, the others are inactive.

H19 TRANSMIT MODE STATUS

This command will transmit through the RS232 serial port the status of the indexer modes. This H Code can be executed while

The format for the data transfer is as follows:

00000000CRLF

n..... 0=PROG EXECUTION INACTIVE	1=PROGRAM EXECUTION ACTIVE
.n..... 0=MOTION INACTIVE	1=MOTION ACTIVE
..n.... 0=INCREMENTAL MODE SELECTED	1=ABSOLUTE MODE SELECTED
...n.... 0=ALL WINDINGS OFF CANCELLED	1=ALL WINDINGS OFF ENABLED
....n... 0=BOOST CURRENT CANCELLED	1=BOOST CURRENT ENABLED
.....n.. 0=REDUCE CURRENT CANCELLED	1=REDUCE CURRENT ENABLED
.....n. 0=LOW SPEED MODE SELECTED	1=HIGH SPEED MODE SELECTED
.....n 0=STEP MODE SELECTED	1=JOG MODE SELECTED

EXAMPLE: If **H19** CRLF results in 00100011CRLF being transmitted, jog mode, high speed mode and absolute mode are enabled.

H20 TRANSMIT I/O STATUS

This command causes the indexer to transmit the status of the two inputs and the two outputs. This H code can be executed while the indexer is in motion, executing a program or in parallel mode.

The format for the data transfer is as follows:

00000000CRLF			
0000n...	INPUT 2	0=inactive	1=active
0000.n..	INPUT 1	0=inactive	1=active
0000..n.	OUTPUT 2	0=inactive	1=active
0000...n	OUTPUT 1	0=inactive	1=active

EXAMPLE: If **H20** CRLF results in 00001001CRLF being transmitted, then output 1 and input 2 are active, and output 2 and input 1 are inactive.

H23 TRANSMIT SOFTWARE REVISION DATE

This command causes the indexer to transmit the software revision date via the RS232 serial interface port.

The date is transmitted in the following format:

INDH mm/yy/xCRLF

Where INDH=indexer, mm=month, yy=year or the software revision and x=software level

EXAMPLE: **H23** CRJLF results in INDH 04/87/C being transmitted, which indicates that indexer software level C was released in April of 1987.

H24 ENABLE TRACE MODE

This command causes the indexer to transmit the contents of each line being executed during program execution.

The data is transmitted in the same format as an **H13** transfer.

NOTE: TRACE MODE MUST BE OFF TO OPERATE WITH AN SSP-500 INDEXER PROGRAMMER

H25 DISABLE TRACE MODE

This command causes the indexer to disable the trace mode during program execution. Upon power up, the indexer is set in the trace disabled mode.

NOTE: The following H codes are able to be executed while the indexer is in motion, executing a program, or in parallel mode: H15, H17, H18, H19, and H20. These codes enable the user to monitor the indexer "on the fly". Each command must be immediately followed with a carriage return and/or line feed during "on the fly" operations.

4.5 N, G, X, F Codes: PROGRAMMING CODES

N[nnn] LINE NUMBER

This command will set the program line pointer to the line specified by [nnn].

[nnn] can have a value from 0 to 400.

Powerup default **N**: [nnn] = The line number in the **L41** parameter.

If a line number greater than 400 is entered, the program line pointer will reset to the line number specified with the **L41** parameter.

NOTE: If program line 00 (N00) is used at any time, the MANUAL DATA INTERFACE mode (MDI) will be enabled.

Program line 00 is stored in a volatile memory only and its contents will be lost when power is removed from the indexer.

N00 is used to store a single program line for manual operation and will not change the contents of the stored program. Upon power up, the MDI line's F code is loaded with the contents of the **L09** parameter.

X [nnnnnnnn] MOVE DIRECTION AND DISTANCE

If in incremental mode, the motor will move in either the +(clockwise) or -(counterclockwise) direction for the distance specified, in pulses. If in absolute mode, the motor will move to the absolute position specified in the X field.

The X field range is from 0 pulse to 99,999,999 pulses.

The **X** field is also used with the **G04, G11, G20, G22** and **G47** commands to specify additional data. See the descriptions of the **G04, G11, G20, G22** and **G47** commands for additional information.

NOTE: No motion can be programmed on a line that contains a G04, G11, G20, G22, G30, G31, G37 or G47 command.

F [nnnnnnnn] FEEDRATE

This command is used to specify the motor speed, in pulses/second, at which a move will occur.

The range of **F** [nnnnnnnn] is:

0 to 115,000 pulses/second if the **L70** parameter is 1, 2, 5, 10

0 to 1,875,000 pulses/sec if the **L70** parameter is 125

The F field is also used with **G11** and **G20** commands to specify additional data.

NOTE: A FEEDRATE SHOULD BE SPECIFIED IN THE FIRST LINE OF THE PROGRAM.

If no FEEDRATE is specified as part of the program line, the last FEEDRATE that was programmed will be used.

G Codes PROGRAMMABLE COMMANDS

G codes are preparatory commands that are stored and executed within a program. Several G codes are modal commands which are those functions that retain their state until canceled or superseded by a subsequent command. **Attempting to execute a G code without required additional data causes program execution to halt and the line number is loaded with the L41 parameter.**

G04 DWELL TIME

This command allows a delay to be entered in the program. The command **G04** must be followed by an X field value that is the desired delay in milliseconds. The X value range is 0 to 9999 msec and any sign is ignored. The correct format for entering a delay is:

N001 G04 X1000 CRLF

G04 calls for a delay and X1000 sets the delay at 1000 milliseconds.

NOTE: The F field value is ignored during the execution of a G04 command.

If any value is entered that is greater than 9999, it will automatically be truncated to the four least significant digits. Therefore, entering N120 **G04** X612000 CRLF will cause a delay of 2000 milliseconds.

Dwell time accuracy is $\pm 2.5\%$ of the selected value.

G11 CALL A SUBROUTINE

This command calls a subroutine.

A **G11** command must be followed by an X value that gives the starting line number of the subroutine and an F value that is the number of times the subroutine is to be repeated.

The range for the **X** value is 1 to 400 (with the sign being ignored); the range for the **F** VALUE IS 0 to 9999. The correct format for a subroutine call is:

"N001 G11 X15 F1 CRLF"

This will set the program line pointer to line 15 and execute the subroutine twice.

See the **G30** command for terminating a subroutine.

NOTE: Using an F value for 0 will cause the subroutine to be executed once; an F value of 1 will cause the subroutine to be executed twice, etc. The number of executions is the F field value +1.

The F field cannot be left blank as this may cause the program to hang up.

NOTE: Subroutines can not be nested. Trying to execute a G11 command while a G11 subroutine call is in progress will cause program execution to cease and the program line pointer will automatically reset to the L41 value.

The X field value is truncated to the four least significant digits. The only values that are valid are numbers from 1 to 400. A 0 or a number greater than 400 will cause program execution to cease and the program line pointer will reset to the **L41** value. The F field value is also truncated to the four least significant digits.

G20 CONDITIONAL BRANCH (L45 = 0)

This command consists of a **G20**, and X value and an F value. The **G20** command will cause the program line pointer to jump to the program line number given by the F field if the state of the two inputs correspond to the values of the X field.

The acceptable values for the X field are:

x [n2] [n1]

n1 = 0 = input 1 inactive

n1 = 1 = input 1 active

n2 = 0 = input 2 inactive

n2 = 1 = input 2 active

Any value for n1 or n2 from 2 to 9 will signify a "don't care" condition and that input will be ignored.

If the states of input 1 and input 2 **match** the values of n1 and n2, the program will jump to the line number indicated by the F field value (1 TO 400 ONLY).

If the states of input 1 and input 2 **do not match** the programmed values of n1 and n2, the program line pointer is incremented to the next program line.

G20 OPTIONS:

G20 X00: Go to line number (F field) if input 2 off and input 1 off

G20 X01: Go to line number (F field) if input 2 off and input 1 on

G20 X10: Go to line number (F field) if input 2 on and input 1 off

G20 X11: Go to line number (F field) if input 2 on and input 1 on

G20 X0d: Go to line number (F field) if input 2 off, ignore input 1

G20 X1d: Go to line number (F field) if input 2 on, ignore input 1

G20 Xd0: Go to line number (F field) if input 1 off, ignore input 2

G20 Xdd: Go to line number (F field) ignore input 2, ignore input 1

d = 2 through 9: don't care condition

EXAMPLE: N100 G20 X22 F120 CRLF

Will always cause a jump to line 120 when executed because both n1 and n2 signify a "don't care" condition.

N100 G20 X01 F120 CRLF

When executed, will cause a jump to line 120 if input 1 is active and input 2 is inactive. Otherwise, the program will increment to line 101.

The F field value is truncated to the least four significant digits, and if the F field value is 0 or greater than 400, program execution will cease and the program line pointer will be set to the **L41** parameter.

G20 CONDITIONAL BRANCH (L45 = 0)

This command consists of a **G20**, an X value and an F value.

The **G20** command will cause the program line pointer to jump to the program line number given by the F field if the state of the four inputs correspond to the values of the X field.

The acceptable values for the X field are:

x [n4][n3][n2][n1]
n1 = 0 = input 1 inactive
n1 = 1= input 1 active
n2 = 0 = input 2 inactive
n2 = 1 = input 2 active
n3 = 0 = CW limit input (input 3) inactive
n3 = 1 = CW limit input (input 3) active
n4 = 0 = CCW limit input (input 4) inactive
n4 = 1 = CCW limit input (input 4) active

Any value for n1, n2, n3, or n4 from 2 to 9 will signify a "don't care" condition and that input will be ignored.

If the states of the four inputs **match** the values of n1, n2, n3, and n4, the program will jump to the line number indicated by the F field value (1 TO 400 ONLY).

If the states of the four inputs **do not match** the programmed values of n1, n2, n3, and n4, the program line pointer is incremented to the next program line.

G20 OPTIONS:

G20 X0000: Go to line number (F field) if input 4 off, input 3 off, input 2 off, input 1 off

G20 X0001: Go to line number (F field) if input 4 off, input 3 off, input 2 off, input 1 on

G20 X0010: Go to line number (F field) if input 4 off, input 3 off, input 2 on, input 1 off

G20 X0011: Go to line number (F field) if input 4 off, input 3 off, input 2 on, input 1 on

G20 X0100: Go to line number (F field) if input 4 off, input 3 on, input 2 off, input 1 off

G20 X0101: Go to line number (F field) if input 4 off, input 3 on, input 2 off, input 1 on

G20 X0110: Go to line number (F field) if input 4 off, input 3 on, input 2 on, input 1 off

G20 X0111: Go to line number (F field) if input 4 off, input 3 on, input 2 on, input 1 on

G20 X1000: Go to line number (F field) if input 4 on, input 3 off, input 2 off, input 1 off

G20 X1001: Go to line number (F field) if input 4 on, input 3 off, input 2 off, input 1 on

G20 X1010: Go to line number (F field) if input 4 on, input 3 off, input 2 on, input 1 off

G20 X1011: Go to line number (F field) if input 4 on, input 3 off, input 2 on, input 1 on

G20 X1100: Go to line number (F field) if input 4 on, input 3 on, input 2 off, input 1 off

G20 X1101: Go to line number (F field) if input 4 on, input 3 on, input 2 off, input 1 on

G20 X1110: Go to line number (F field) if input 4 on, input 3 on, input 2 on, input 1 off

G20 X1111: Go to line number (F field) if input 4 on, input 3 on, input 2 on, input 1 on

Any 0 or 1 can be replaced by a "don't care" character (2 through 9). A "don't care" condition causes that particular input to be ignored.

EXAMPLE:

N100 **G20** X2222 F120

Will always cause a jump to line 120 because all inputs signify a "don't care" condition.

N100 **G20** X1010 F120 CRLF

When executed, will cause a jump to line 120 if 4 is active, input 3 is inactive, input 2 is active, and input 1 is inactive. Otherwise, the program will increment to line 101.

The F field value is truncated to the least four significant digits, and if the F field value is 0 or greater than 400, program execution ceases and the line number is set with the **L41** parameter.

G22 WAIT FOR INPUT (L45 = 0)

This command consists of a **G22** and X field.

The **G22** command will cause the program to wait until the state of the two inputs correspond to the values of the X field.

The acceptable values for the X field are:

x [n2] [n1]

n1 = 0 = input 1 inactive
n1 = 1 = input 1 active
n2 = 0 = input 2 inactive
n2 = 1 = input 2 active

Any value for n1 or n2 from 2 to 9 will signify a "don't care" condition and that input will be ignored.

If the states of input 1 and input 2 **match** the values of n1 and n2, the program continues execution.

If the states of input 1 and input 2 **do not match** the programmed values of n1 and n2, the program waits until a match occurs.

N100 **G22** X10 CRLF

When executed will cause the program to wait until input 2 is active and input 1 is inactive. Then, the program will increment to line 101.

The F field is ignored during a **G22** command.

G22 OPTIONS:

G22 X00: Wait until input 2 off, input 1 off

G22 X01: Wait until input 2 off, input 1 on

G22 X10: Wait until input 2 on, input 1 off

G22 X11: Wait until input 2 on, input 1 on

G22 X0d: Wait until input 2 off, ignore input 1

G22 X1d: Wait until input 2 on, ignore input 1

G22 Xd0: Wait until input 1 off, ignore input 2

G22 Xd1: Wait until input 1 on, ignore input 2

G22 Xdd: Don't wait

d = 2 through 9: don't care condition

G22 WAIT FOR INPUT (L45 = 1)

This command consists of a **G22** and X field.

The **G22** command will cause the program to wait until the state of the four inputs correspond to the values of the X field.

The acceptable values for the X field are:

x [n4] [n3] [n2] [n1]
n1 = 0 = input 1 inactive
n1 = 1 = input 1 active
n2 = 0 = input 2 inactive
n2 = 1 = input 2 active
n3 = 0 = CW limit input (input 3) inactive
n3 = 1 = CW limit input (input 3) active
n4 = 0 = CCW limit input (input 4) inactive
n4 = 1 = CCW limit input (input 4) active

Any value for n1, n2, n3, or n4 from 2 to 9 will signify a "don't care" condition and that input will be ignored.

If the state of the four inputs **match** the values of n1, n2, n3 and n4, the program continues execution.

If the states of the four inputs **do not match** the programmed values of n1, n2, n3 and n4, the program waits until a match occurs.

G22 OPTIONS:

G22 X0000: Wait until input 4 off, input 3 off, input 2 off, input 1 off

G22 X0001: Wait until input 4 off, input 3 off, input 2 off, input 1 on

G22 X0010: Wait until input 4 off, input 3 off, input 2 on, input 1 off

G22 X0011: Wait until input 4 off, input 3 off, input 2 on, input 1 on

G22 X0100: Wait until input 4 off, input 3 on, input 2 off, input 1 off

G22 X0101: Wait until input 4 off, input 3 on, input 2 off, input 1 on

G22 X0110: Wait until input 4 off, input 3 on, input 2 on, input 1 off

G22 X0111: Wait until input 4 off, input 3 on, input 2 on, input 1 on

G22 X1000: Wait until input 4 on, input 3 off, input 2 off, input 1 off

G22 X1001: Wait until input 4 on, input 3 off, input 2 off, input 1 on

G22 X1010: Wait until input 4 on, input 3 off, input 2 on, input 1 off

G22 X1011: Wait until input 4 on, input 3 off, input 2 on, input 1 on

G22 X1100: Wait until input 4 on, input 3 on, input 2 off, input 1 off

G22 X1101: Wait until input 4 on, input 3 on, input 2 off, input 1 on

G22 X1110: Wait until input 4 on, input 3 on, input 2 on, input 1 off

G22 X1111: Wait until input 4 on, input 3 on, input 2 on, input 1 on

Any 0 or 1 can be replaced by a "don't care" character (2 through 9). A "don't care" condition causes that particular input to be ignored.

EXAMPLE:

N100 G22 X1010 CRLF

When executed will cause the program to wait until input 4 is active, input 3 is inactive, input 2 is active, and input 1 is inactive. Then the program will increment to line 101.

G30 RETURN FROM SUBROUTINE/PROGRAM END

This command has two uses.

1. **G30**, used in conjunction with a **G11**, indicates end of a subroutine. A **G30** command that is issued after a **G11** command will cause the program line pointer to be set to the next program line **after** the line containing the **G11** command.
2. **G30**, used by itself, that is not following a **G11** command, indicates the **end of the program**.

The program line pointer will reset to the program line indicated by the **L41** parameter.

In the **automatic execution format**, (**L06 n = 2**), **G30** will stop program execution.

In the **continuous execution format** (**L06 n = 3**), program execution will continue from the line number indicated by the **L41** parameter.

If no **G30** command is used, program line number 400 is automatically set as the end of the program.

G31 PROGRAM STOP

During program execution, the **G31** causes the program to cease executing and the line pointer increments to the next line. A CYCLE START (H1) will continue execution from that point.

G36 STROBE X CODE DATA

During program execution, the **G36** command causes the indexer to load the parallel data inputs. The Field Data entry becomes the X field for the program line. The Select and Code Data entries are ignored. The program line's F Code, if programmed, will be utilized as the active feed rate. Any previously programmed X field on a line with a **G36** command is ignored.

G37 STROBE N CODE DATA

During program execution, the **G37** command causes the indexer to load the parallel data inputs. The Code Data entry becomes the active program line as the program branches to that line. The Select and Field Data entries are ignored. Any previously programmed X or F fields on a line with a **G37** command are ignored. Attempting to load a line number of 0 or greater than 400 will cause program execution to cease, and the program line pointer will reset to the **L41** value.

G47 SET OUTPUT

This command will set the states of the two programmable outputs according to the value of the last 2 digits of the X field in the following fashion:

G47 X[n2] [n1]

- n1 = 0 = output 1 off (inactive)
- n1 = 1 = output 1 on (active)
- n2 = 0 = output 2 off (inactive)
- n2 = 1 = output 2 on (active)

If a value of 2 through 9 is used for n1 or n2, it will not change the state of the output.

G47 OPTIONS

G47 X00 = Output 2 off, output 1 off
G47 X01 = Output 2 off, output 1 on
G47 X10 = Output 2 on, output 1 off
G47 X11 = Output 2 on, output 1 on
G47 X0d = Output 2 off, output 1 no change
G47 X1d = Output 2 on, output 1 no change
G47 Xd0 = Output 2 no change, output 1 off
G47 Xd1 = Output 2 no change, output 1 on
G47 Xdd = Output 2 no change, output 1 no change
d = 2 through 9, don't care condition

The F field is ignored on a line containing a G47 command.

* The following four commands apply to 3180 and 6180 series drives only. They are not functional with 230 and 430 series units.

G64 ENABLE REDUCED CURRENT *

This command will reduce the motor current at standstill to a value set on the drive. If a command for motion is issued after a G64 command, the motor will run at normal current, and return to a reduced current when motion ceases.

G65 CANCEL REDUCED CURRENT *

This command cancels the G64 command. When the indexer is powered up, it is in the CANCEL REDUCED CURRENT mode.

G66 ENABLE BOOST CURRENT *

This command will increase the motor current during acceleration and deceleration to a value set on the drive. The boost will turn off 5 seconds after application to prevent excessive motor heating during long acceleration/deceleration ramps.

G67 CANCEL BOOST CURRENT *

This command cancels the G66 command. When the indexer is powered up, it is in the CANCEL BOOST CURRENT mode.

G68 ENABLE ALL WINDINGS OFF

This command sets the average motor current to zero when the motor is at a standstill. Voltage is still present at the motor terminals.

If a command for motor motion is issued after a G68 command, the motor will turn at normal current and return to a zero condition when motion ceases.

G69 CANCEL ALL WINDINGS OFF

This command cancels a G68 command.

When the indexer is powered up, it is in the CANCEL ALL WINDINGS OFF mode.

G76 RETURN TO ELECTRICAL HOME

This command causes the motor to turn until an absolute position of 0 is reached.

Electrical home is established when the indexer is powered up or when a H09 SET HOME command is used.

The motor will move in the **opposite direction of the absolute position sign** and will index the value contained in the absolute position counter.

G77 SET ELECTRICAL HOME

This command sets the absolute position counter to zero. The current motor position is established as electrical home.

G78 RETURN TO MECHANICAL HOME

This command causes the motor to turn in the direction set with the L08 parameter, at the speed set with L14 until the home limit switch is activated. The motor then offsets from the switch the direction and distance set with the L17 parameter at the speed set with L14. At motion completion, the motor position becomes electrical home as the absolute position counter is set to zero.

G90 ABSOLUTE MODE

This command sets the indexer to operate in the absolute mode. All moves made by the motor are counted either plus or minus from the **zero position** set with the H09 or G77 command.

G91 INCREMENTAL MODE

This command sets the indexer to operate in the incremental mode.

All moves of the motor are counted either plus or minus from the **present motor position**.

When the indexer is powered up, it is automatically set in the INCREMENTAL MODE.

NOTE: Even when the indexer is operating in the incremental mode, the ABSOLUTE POSITION counter is operational and a RETURN TO ELECTRICAL HOME command may be used.

4.6 SAMPLE PROGRAM

DESCRIPTION

The following is a sample program which demonstrates some of the capabilities of the Micro Series indexer. With **L06** set to 3, **L41** at 1 and **L45** at 0, lines 1 through 3 will execute continuously until an input condition matches the branch condition and jumps to the branch line number.

Selecting program segment 1 through input 1 results in the following lines being executed:
20, 21, 22, 23, 24, 25, 26, 27, 28, 29, and back to 1.

Selecting program segment 2 through input 2 results in the following lines being executed:
10, 11, 12, 13, 14, 15, 16, 30, 31, 32, 33, 34, 30, 31, 32, 33, 34, 30, 31, 32, 33, 34, 17, 18, 19, and back to 1

N001 G20 X + 00000010 F0000010	Line 1 is a CONDITIONAL BRANCH. If input 2 is active and input 1 is inactive, the line pointer jumps to line 10.
N002 G20 X + 0000001 F0000020	Line 2 is a CONDITIONAL BRANCH. If input 2 is inactive and input 1 is active, the line pointer jumps to line 20.
N003 G30	Line 3 is a PROGRAM END. The L41 Value (1) is loaded in the line pointer and since L06 is set in the continuous mode (3), the program continues to execute.
N004	Line 4 contains no programming.
N005	Line 5 contains no programming.
N006	Line 6 contains no programming.
N007	Line 7 contains no programming.
N008	Line 8 contains no programming.
N009	Line 9 contains no programming.
N010 G90 X + 00001000 F0002400	Line 10 sets ABSOLUTE MODE with G90 and the motor moves to position +1000 at a FEEDRATE of 2400 pulses/sec.
N11 G04 X +00002000	Line 11 is a DWELL time of 2 seconds.
N012 X - 00002000	Line 12 moves to position -2000 by moving -3000 pulses at a FEEDRATE of 2400 pulses/sec. (Since no feedrate was programmed, it moved at the last programmed feedrate.)
N013 G66 X + 00010000 F0001200	Line 13 ENABLES BOOST CURRENT with G66 and the motor moves to position +10000 by moving +12000 pulses at a FEEDRATE of 1200 pulses/sec.
N014 G04 X + 00003000	Line 14 is a DWELL of 3 seconds.
N015 G67 X - 00003000 F0002000	Line 15 CANCELS BOOST CURRENT WITH G67 and the motor moves to position -3000 by moving -13000 pulses at FEEDRATE of 2000 pulses/sec.
N016 G11 X + 00000030 F0000002	Line 16 is a SUBROUTINE CALL to line 30. The subroutine will be executed 3 times.
N017 G76	Line 17 RETURNS HOME (position 0) by moving the necessary pulses at the HOME SPEED (L14).
N018 G47 X + 00000001	Line 18 turns off output 2 and turns output 1 on.
N19 G20 X + 00000022 F0000001	Line 19 is an UNCONDITIONAL BRANCH to Line 1.
N020 G91 X -00002500 F0002400	Line 20 sets INCREMENTAL MODE with G91 and the motor moves -2500 pulses at a FEEDRATE OF 2400 pulses/sec.

N021 G64 X + 00000500	Line 13 ENABLES REDUCE CURRENT with G64 and the motor moves +500 pulses at a FEEDRATE of 2400 pulses/sec. (Since no feedrate was programmed, it moved at the last programmed feedrate.)
N022 G04 X + 00004000	Line 22 is a DWELL of 4 seconds.
N23 G65 X + 00005500	Line 23 CANCELS REDUCE CURRENT with G65 and moves the motor +5500 pulses at a FEEDRATE of 2400 pulses/sec. (Since no feedrate was programmed, it moved at the last programmed feedrate.)
N24 G68 X - 00009120 F0002000	Line 24 ENABLES ALL WINDINGS OFF with G68 and the motor moves -9120 pulses at a FEEDRATE of 2000 pulses/sec.
N025 G04 X +000009000	Line 25 is a DWELL of 9 seconds.
N26 G69	Line 26 CANCELS ALL WINDINGS OFF with G69.
N027 G76	Line 27 RETURNS HOME (position 0) by moving the necessary pulses at the HOME SPEED (L14).
N028 G47 X +00000010	Line 28 turns off output 1 and turns output 2 on.
N029 G20 X + 00000022 F0000001	Line 29 is an UNCONDITIONAL BRANCH to Line 1, effectively ending the second program segment.
N030 X - 00000100 F0000800	Line 30 moves the motor to position -100 at a FEEDRATE of 800 pulses/sec.
N031 G04 X + 00005000	Line 31 is a DWELL of 5 seconds.
N032 X + 00000500 F0001500	Line 32 moves the motor to position +500 at a FEEDRATE of 1500 pulses/sec.
N033 G04 X + 00003500	Line 33 is a DWELL of 3.5 seconds.
N034 G30	Line 34 is a SUBROUTINE END.

4.7 CODE ASSIGNMENT TABLES

PARAMETERS

code	field data	function
L06	n	Execute Format (1, 2, 3)
L07	nnnn	Strobe delay Time (milliseconds)
L08	s	Mechanical Home Direction (+, -)
L09	nnnnnn	Jog Speed (pulse/sec)
L11	nnnnnnn	Acceleration/Deceleration (pulses/sec/sec)
L12	nnnnnnn	Low Speed (pulses/sec)
L14	nnnnnnn	Home Speed (pulses/sec)
L17	snnnnnnnn	Offset Distance and Direction from Home (pulses)
L18	snnnnnnnn	CW software Travel Limit (pulses)
L19	snnnnnnnn	CCW software Travel Limit (pulses)
L21	nn	RS232 Device ID (01 thru 99)
L22	nnnn	RS232 Baud Rate (300, 1200, 2400, 9600)
L23	n	RS232 Word Length (7, 8)
L25	n	RS232 Parity (1, 2, 3)
L26	n	Indexer Ready Acknowledge (0, 1, 2, 3)
L41	nnn	Line Number for Auto Start (00 through 400)
L44	nnnn	Program Line Delay (milliseconds)
L45	n	Limit Switch Enable (0, 1)
L48	nnn	Program Line Count
L49	nn	Parameter Transfer Designation
L70	nnn	Translator Resolution (1, 2, 5, 10, 125)

COMMANDS

code	type	function
H06	motion	Cycle Start
H06	motion	CW Direction for STEP or JOG mode
H07	motion	CCW Direction for STEP or JOG mode
H08	motion	Return to Electrical Home
H09	motion	Set Home
H10	motion	Return to Mechanical Home
*	motion	Clear (uncontrolled stop)
\$	motion	Feed hold (controlled stop)
#	motion	Stop Program Execution Cycle
H02	mode	set Step Mode
H03	mode	set Jog Mode
H04	mode	set High Speed Mode operation
H05	mode	set Low Speed Mode of operation
H11	edit	Clear present Program Line
H12	edit	Clear Program
<nn	edit	Device Attention Character
Cntl H	edit	Back Space
Cntl X	edit	Cancel Line
H13	transfer	transfer Present Program Line
H14	transfer	transfer Program
H15	transfer	transfer Present Line Number (see note)
H16	transfer	transfer Parameters
H17	transfer	transfer Absolute Position (see note)
H18	transfer	transfer Motion Status (see note)
H19	transfer	transfer Mode Status (see note)
H20	transfer	transfer I/O Status (see note)
H23	transfer	transfer Software Revision Date
H24	mode	enable Trace Mode
H25	mode	disable Trace Mode

NOTE: H15, H17, H18, H19, and H20 can be executed during motion or program execution, and also while in parallel mode, to obtain "on the fly" information.

PROGRAM DATA

code	field data	function
N	nnn	Line Number (000 thru 400)
X	snnnnnnnn	Move Distance or Data field for G04, G11, G20, G22, G47 codes
F	nnnnnnn	Feed Rate or Data field for G11, G20 codes
code	function	X field data
G04	Program Dwell Time	nnnn Dwell in milliseconds
G11	Subroutine call	nnn Line Number of Subroutine
G20	Conditional Branch	(nn)nn Input condition for Branch
G22	Wait for Input	(nn)nn Input Wait Condition
G30	Return from Subroutine/ Program End	
G31	Program Stop	
G36	Strobe X Code Data	
G37	Strobe N Code Data	
G47	Set/Reset Output Condition	nn Output condition
G64	Enable Reduce Current Mode	
G65	Cancel Reduce Current Mode	
G66	Enable Boost Current Mode	
G67	Cancel Boost Current Mode	
G68	Enable All Windings Off Mode	
G69	Cancel All Windings Off Mode	
G76	Return To Electrical Home	
G77	Set Electrical Home	
G78	Return to Mechanical Home	
G90	Set Absolute Motion Mode	
G91	Set Incremental Motion Mode	

SECTION 5: OPERATING INSTRUCTIONS

5.1 OVERVIEW

The Micro-Indexer allows for program entry and execution from a variety of sources. The options are:

- Operation from a user-made switch panel.
- Operation from Superior Electric switch panel SSP-100. These options are discussed in Section 5.2.
- Operation from a Superior Electric SSP-500 hand-held intelligent terminal.
- Operation from a user supplied remote terminal. These options are covered in Section 5.3.
- Operation from a host computer. This option is covered in Section 5.4.

5.1.1 Instructions for Entering Data

5.1.1.1 General Instructions

1. Lines may be programmed in any order but are executed in numerical sequence.
2. Variables may be programmed or reprogrammed in any order.
3. Program area should be cleared prior to new program entry to avoid execution of previously programmed lines.

4. If feed rate is not programmed for a given line, the last programmed feed rate is used.

5. Selection of invalid data will result in the previous data being left intact.

5.2 OPERATION FROM A SWITCH PANEL

5.2.1 Overview

Because of the nature of the parallel interface, all indexer functions can be controlled by the connection of one of 8 STROBE pins to one of 8 DATA pins. A matrix diagram of the STROBE/DATA functions is given in Figure 5.1.

Referring to this figure, it can be seen that if the STROBE 0 line is connected to the DATA 2 line, a Home Limit condition will be indicated.

All STROBE/DATA functions are controlled by either STROBE 0 or STROBE 1. These two STROBE lines are polled by the indexer every several milliseconds, so that any contact closure between STROBE 0 or STROBE 1 and any of the DATA lines will be detected by the indexer within a maximum of 12 milliseconds. Figure 5.3 shows a strobe signal timing diagram.

The other STROBES listed in Figure 5.1 are used to enter programs and parameters. After switches are set, the LOAD input must be activated for data entry to be executed (LOAD is a connection between STROBE 1 and DATA 2).

STROBE/DATA FUNCTION MATRIX DIAGRAM

INPUT	STROBE 0 MOTION	STROBE 1 MOTION	STROBE 2 MOTION	STROBE 3 MOTION	STROBE 4 MOTION	STROBE 5 MOTION	STROBE 6 MOTION	STROBE 7 MOTION
D0	CW LIMIT	CW DIR	CODE 1	CODE100	DATA 1M	DATA 10K	DATA 100	DATA 1
D1	CCW LIMIT	CCW DIR	CODE 2	CODE 200	DATA 2M	DATA 20K	DATA 200	DATA 2
D2	HOME LIMIT	LOAD	CODE 4	CODE 400	DATA 4M	DATA 40K	DATA 400	DATA 4
D3	CLEAR CYCLE	AWO	CODE 8	CODE 800	DATA 8M	DATA 80K	DATA 800	DATA 8
D4	FEED HOLD	LOW/HIGH	CODE 10	SIGN	DATA 10M	DATA 100K	DATA 1K	DATA 10
D5	IN 1	STEP/JOG	CODE 20	SEL 1	DATA 20M	DATA 200K	DATA 2K	DATA 20
D6	IN 2	CYCLE START	CODE 40	SEL 2	DATA 40M	DATA 400K	DATA 4K	DATA 40
D7	STOP CYCLE	SER/PAR	CODE 80	SEL 4	DATA 80M	DATA 800K	DATA 8K	DATA 80

NOTE: All signals are low true logic except LOW, STEP and SER.

Figure 5.1, Strobe and Data Functions

PARALLEL INPUT EVALUATION

Due to necessary timing restrictions, not all inputs are monitored at all times. Below is a description of which inputs are active and when.

Inputs must be active for a minimum of 12 milliseconds to be considered valid.

SERIAL MODE				PARALLEL MODE			
INPUT	PROGRAM EXECUTION	MANUAL MOTION	READY MODE	PROGRAM EXECUTION	MANUAL MOTION	PARALLEL DATA LOAD	READY MODE
CW LIMIT	•	•		•	•		
CCW LIMIT	•	•		•	•		
HOME LIMIT	•	•		•	•		
CLEAR	•	•	•	•	•	•	•
FEEDHOLD	•	•		•	•		
CW DIRECTION					•		•
CCW DIRECTION					•		•
CYCLE STOP	•			•			
INPUT 1	•			•			
INPUT 2	•			•			
LOAD							•
AWO							•
LOW/HIGH							•
STEP/JOG							•
CYCLE START	•		•	•			•
SERIAL/PARALLEL			•				•
CODE 1-CODE 800					•		
DATA 1-DATA 80M					•		
SIGN					•		
SEL 1, SEL 2, SEL 4					•		

5.2.2 Data Entry Switch

The schematic diagram shown in Figure 5.2 gives the wiring details for the construction of a Parallel Data Entry Interface.

NOTE: Implementation of steering diodes is essential to insure proper operation.

The SSP-100, A fully functional parallel interface data entry switch panel, can be ordered from Superior Electric.

The following table gives a summary of the data entry format.

FUNCTIONAL SELECT	CODE DATA THUMBWHEEL	FIELD DATA THUMBWHEEL
N = Line No.	Line Number	Not Used
G Code	G Code Selection	Not Used
X Code	Not Used	X Field Data
F Code	Not Used	F Field Data
L Code	L Code Selection	L Field Data
H Code	H Code Selection	Not Used




FIGURE 5.2 SWITCH PANEL CONNECTION

5.2.3 Description Of Hardware Inputs

CODE DATA THUMBWHEEL	Input for entry of line number, L, H or G code	CYCLE STOP-	Program execution is stopped after the present line is executed.		
FIELD DATA THUMBWHEEL	Input for entry of data associated with the X field, F field or L field data	LOAD-	Input to enter data selected on CODE DATA thumbwheel and corresponding data on FIELD DATA thumbwheel.		
CW LIMIT-	Input to cause motion to come to an uncontrolled immediate stop if moving in the CW direction. Motion is only allowed in the CCW direction until the CW Limit- is inactive. Line pointer is reset to L41 value, serial buffer is cleared and XOFF and then XON are sent.	AWO-	Input to turn windings off when the motor is at a standstill.		
CCW LIMIT-	Input to cause motion to come to an uncontrolled immediate stop of moving in the CCW direction. Motion is only allowed in the CW direction until the CCW Limit- is inactive. Line pointer is reset to L41 value, serial buffer is cleared and XOFF and then XON are sent.	LOW/HIGH-	Input to determine speed range limit. If HIGH- is selected, motor will be allowed to ramp to selected speed. If LOW is selected, motor will not be allowed to ramp and will run at selected low speed.		
CLEAR-	Input to cause motion to come to an uncontrolled immediate stop. Position is lost, no motion is allowed while CLEAR- is active. Resets line pointer to L41 value, clears the serial buffer and XOFF and then XON are sent.	STEP/JOG-	Input to determine if motor will single-step or jog (continuous motion) when manual motion is called for.		
FEEDHOLD-	Input to cause motion to come to a controlled stop (pause) with no loss of position.	CYCLE START-	Input to start execution of program or to continue motion if a FEED HOLD has been executed.		
HOME LIMIT-	Input to indicate mechanical home position.	SERIAL/PARALLEL-	Input to determine if operation is via SERIAL (RS232) or PARALLEL inputs. If SERIAL mode is selected, the following parallel inputs are ignored. CW DIR-, CCW DIR-, LOW/HIGH-, AWO-, STEP/JOG-, LOAD-		
CW DIR-	Input to cause motor motion in the CW direction. If STEP was selected, motor will single-step each time this input is activated. If JOG- is selected, motor will turn continuously while input is active.	SEL 4-, SEL 2-, SEL 1-	Changing this input automatically invokes a CLEAR command. FUNCTION SELECT inputs SEL 4-, SEL 2- and SEL 1- are used in combination to select the variable to be programmed on a selected line.		
CCW DIR-	Input to cause motor motion in the CCW direction. If STEP was selected, motor will single-step each time this input is activated. If JOG- is selected, motor will turn continuously while input is active.	<u>SEL 4-</u>	<u>SEL 2-</u>	<u>SEL 1-</u>	<u>Function Selected</u>
		0	0	0	N Line Number
		0	0	1	G Code
		0	1	0	X Code
		0	1	1	F Code
		1	0	0	L Code
		1	0	1	H Code
		1	1	0	Not Used
		1	1	1	Not Used

NOTE: 0=high input

1=low input

Minus sign (-) indicates signal is active when low.

5.2.4 PARALLEL DATA LOADING

- 1) Parallel mode must be selected
- 2) Program execution and manual modes must be stopped
- 3) The proper data must be selected via the function select switches, code data thumbwheels and field data thumbwheels.
- 4) The load input must be activated.

EXPLANATION OF HOW INDEXER LOADS PARALLEL DATA

- 1) Strobe 0 and Strobe 1 are disabled.
- 2) Strobe 2 is activated for the delay time indicated by the L07 parameter.
- 3) At the end of the delay period the data is read and the strobe deactivated.
- 4) Strobe 3 is activated for the delay time indicated by the L07 parameter.
- 5) At the end of the delay period the data is read and the strobe deactivated.
- 6) Strobe 4 is activated for the delay time indicated by the L07 parameter.
- 7) At the end of the delay period the data is read and the strobe deactivated.
- 8) Strobe 5 is activated for the delay time indicated by the L07 parameter.
- 9) At the end of the delay period the date is read and the strobe deactivated.
- 10) Strobe 6 is activated for the delay time indicated by the L07 parameter.
- 11) At the end of the delay period the data is read and the strobe deactivated.
- 12) Strobe 7 is activated for the delay time indicated by the L07 parameter.
- 13) At the end of the delay period the data is read and the strobe deactivated.
- 14) An additional time delay indicated by the L07 parameter is executed to allow sufficient time to remove the data prior to Strobe 0 and Strobe 1 actuation.
- 15) The command is then executed.

5.2.4.1 Data Entry By Letter Code

Minus sign (-) indicates signal is active when low.

Data Entry N:

1. Select N code via SEL 4-, SEL 2- and SEL 1- inputs.
2. Select desired line number on code data thumbwheel.
3. Bring LOAD- input low and release.
4. Code data thumbwheel value is then strobed in.
5. This becomes the active program line until new line number is selected.
6. Field data thumbwheel value is ignored.

Data Entry G:

1. Select G code via SEL 4-, SEL 2- and SEL 1- inputs.
2. Select desired G code on code data thumbwheel.
3. Bring LOAD- input low and release.
4. Code data thumbwheel value are the strobed in.
5. G code is placed in active program line.
6. Field data thumbwheel value is ignored.

Data Entry X:

1. Select X code via SEL 4-, SEL 2- and SEL 1- inputs.
2. Select desired X value on field data thumbwheel.
3. Bring LOAD- input low and release.
4. Field data thumbwheel value is then strobed in.
5. Value is placed in active program line X field.
6. Code data thumbwheel value is ignored.

Data Entry F:

1. Select F code via SEL 4-, SEL 2- and SEL 1- inputs.
2. Select desired value on the field data thumbwheel.
3. Bring LOAD- input low and release.
4. Field data thumbwheel value is then strobed in.
5. Value is placed in active program line F field.
6. Code data thumbwheel is ignored.




FIGURE 5.3. STROBE TIMING DIAGRAM

Data Entry L:

1. Select L code via SEL 4-, SEL 2- and SEL 1- inputs.
2. Select desired L code data on code data thumbwheel.
3. Select associated value on field data thumbwheel.
4. Bring LOAD- input low and release.
5. Code data thumbwheel value is then strobed in.
6. Field data thumbwheel value is then strobed in.
7. L code is entered.

Data Entry H:

1. Select H code via SEL 4-, SEL 2- and SEL 1- inputs.
2. Select desired H code on code data thumbwheel.
3. Bring LOAD- input low and release.
4. Code data thumbwheel value is then strobed in.
5. H code is executed.
6. Field data thumbwheel is ignored.

NOTE: The following H codes cannot be executed while in parallel mode: H2, H3, H4, H5, H6 and H7.

5.2.4.2 Execution

Manual motion is possible whenever a program is not being executed. The STEP/JOG- input and the LOW/HIGH- input will determine the response to the CW DIR- and CCW DIR- inputs becoming active. The absolute position counter is maintained.

Program Execution is accomplished by activating the CYCLE START- input and releasing. The program then executes based on the L parameters.

5.2.4.3 Outputs Accessed Through The External Parallel I/O Port

These outputs are open collectors. They must be pulled up to an external voltage source (maximum +24Vdc) through a series resistor to limit the sink current to a maximum of 40 milliamperes.

OUTPUT 1-, OUTPUT 2-	Programmable outputs controlled through use of G47 code.
ALL WINDINGS OFF OUT-	Output indicating the status of the ALL WINDINGS OFF- mode.
CW/CCW- OUT	Output indicating the direction of motor motion.
MOTION BUSY OUT-	Output indicating when any type of motion is occurring.
PULSE OUT-	Output of the pulses being applied to the drive.

5.3 OPERATION FROM A REMOTE TERMINAL

5.3.1 Overview

This section contains information pertaining to operating the indexer from a remote terminal via the RS232 serial port.

5.3.2 Connections and Interface

The 9-pin serial interface connector can be used to connect a remote terminal to the indexer for programming and program execution.

The SSP-500, a hand-held intelligent terminal available from Superior Electric, can be used for debugging, loading and executing indexer programs.

When any other type of remote terminal is used with the indexer, the baud rate must be set correctly so that the indexer will match the terminal. This parameter is set with the **L22, L23 and L25** commands. See the Command Description section for the applicable values and defaults.

NOTE: The baud rate, word length and parity default settings are correct for operation with the Superior Electric hand-held remote terminal SSP-500.

If another type of remote terminal is used which has a baud rate other than 9600 baud, the terminal will not be able to communicate with the indexer. A compatible terminal will have to be used to set the baud rate or, alternatively, a switch panel (such as an SSP-100) can be used to set the indexer's baud rate, etc. (See Section 5.2.1 for a description of the switch panel operation).

5.4 OPERATION FROM A HOST COMPUTER

The hardware connections for a host computer are the same as those for a remote terminal. The connection is made through the 9-pin serial interface connector.

An IBM compatible program (on a 5.25" floppy disk) that has editing, manual motion and program execution modes of operation to facilitate Micro Series indexer functions is available from Superior Electric. Local and remote modes allow programs to be developed off-line in the IBM PC and later loaded into the indexer.

Alternatively, a commercially available communications program (such as "Crosstalk", from Digital Communications Associates, Inc.) may be run on the PC to configure it as a remote terminal.

To interface with an IBM PC, the connections must be configured as follows:

IBM (25-pin "D" Connector)	Positioner (9-pin "D" Connector)
Pin Number	Pin Number
2	3 Receive
3	2 Chain Out
7	4 Signal Common

Following are three sample IBM PC compatible programs to display the ease of indexer/host computer software interfacing. Program 1 uploads an indexer program to the PC disk. Program 2 downloads a program from the PC disk to the indexer; and program 3 sets up interactive communications between the PC and the indexer. Enter BASIC with the following:

BASICA/C:4096

PROGRAM LISTING 1

```
10 REM THIS PROGRAM TAKES THE APPLICATION PRO-
    GRAM THAT IS IN
20 REM THE INDEXER AND STORES IT ON A DISK.
25 REM PROGRAM DOES NOT SUPPORT DAISY CHAINING
30 REM CONFIGURE SERIAL PORT 1 FOR INDEXER COM-
    MUNICATIONS
40 REM INDEXER SET AT 9600 BAUD, 8 DATA BITS, 1 STOP
    BIT, AND
50 REM NO PARITY
60 OPEN "COM1:9600, N,8,2,CS,DS,CD" AS#1
70 INPUT "ENTER DEVICE NUMBER";D
80 REM OUTPUT DEVICE CHARACTER AND DEVICE NUM-
    BER
90 IF D>99 OR D<1 GO TO 70
100 REM
110 IF D<10 THEN PRINT #1 USING "<#";D
120 IF D>9 THEN PRINT #1 USING "<##";D
130 REM RECEIVE EQUAL SIGN AND XON
140 G$=INPUT$(2,#1)
150 REM SET L26 PARAMETER TO 0
160 PRINT #1, "L26 0"
170 REM RECEIVE XOFF AND XON
180 G$=INPUT$(2,#1)
190 REM INPUT FILENAME TO WHICH THE INDEXER PRO-
    GRAM WILL BE STORED
200 INPUT "ENTER FILENAME TO STORE INDEXER
    PROGRAM";F$
210 REM OPEN THE DISK FILE TO RECEIVE THE INDEXER
    PROGRAM
220 OPEN "O", #2, F$
230 REM INITIALIZE LINE COUNT
240 C=0
250 REM SEND PROGRAM TRANSFER COMMAND TO IN-
    DEXER
260 PRINT #1,"L48 0 H14"
270 REM INPUT XOFF
280 G$=INPUT$(1,#1)
290 REM RECEIVE PROGRAM LINE
300 INPUT #1, L$
310 REM SEND XOFF TO ALLOW TIME TO STORE DATA ON
    DISK
320 PRINT #1, CHR$(19);
330 REM STORE DATA ON DISK
340 PRINT #2,L$
350 REM DISPLAY PROGRAM LINE ON SCREEN
360 PRINT L$
370 REM INCREMENT LINE COUNT
380 C=C+1
390 REM SEND XON TO ALLOW TRANSMISSION TO CON-
    TINUE
400 PRINT #1, CHR$(17);
410 REM GET NEXT LINE IF 400 LINES HAVE NOT BEEN
    RECEIVED
420 IF C<400 THEN GO TO 300
430 REM DATA TRANSFER AND STORAGE COMPLETE
440 PRINT "INDEXER PROGRAM STORED IN FILE"; F$
```

PROGRAM LISTING 2


```
10 REM THIS PROGRAM LOADS THE INDEXER WITH AN
   APPLICATION PROGRAM
20 REM THAT HAS BEEN STORED ON A DISK
25 REM PROGRAM DOES NOT SUPPORT DAISY CHAINING
30 REM CONFIGURE SERIAL PORT 1 FOR INDEXER COM-
   MUNICATIONS
40 REM INDEXER SET AT 9600 BAUD, 8 DATA BITS, 2 STOP
   BITS AND
50 REM NO PARITY
60 OPEN "COM1:9600,N,8,2,CS,DS,CD" AS#1
70 INPUT "ENTER DEVICE NUMBER";D
80 REM OUTPUT XON
90 PRINT #1,CHR$(17);
100 REM OUTPUT DEVICE CHARACTER AND DEVICE NUM-
   BER
110 IF D>99 OR D<1 THEN GO TO 70
120 REM
130 IF D<10 THEN PRINT #1, USING "<#;D"
140 IF D>9 THEN PRINT #1, USING "<##;D"
150 REM RECEIVE EQUAL SIGN, AND XON
160 G$=INPUT$(2,#1)
170 REM SET L26 PARAMETER TO 0
180 PRINT #1,"L26 0"
190 REM RECEIVE XOFF AND XON
200 G$=INPUT$(2,#1)
210 REM FILENAME FROM WHICH THE INDEXER WILL BE
   LOADED
220 INPUT "ENTER FILENAME TO LOAD INDEXER" ;F$
230 REM OPEN THE DISK FILE TO LOAD INDEXER
240 OPEN "I", #2, F$
250 REM INITIALIZE LINE COUNT
260 C=0
270 REM READ PROGRAM LINE FROM DISK
280 INPUT #2, L$
290 REM SEND PROGRAM LINE TO INDEXER
300 PRINT #1,L$
310 REM INPUT XOFF AND XON
320 G$=INPUT$(2,#1)
330 REM DISPLAY PROGRAM LINE ON SCREEN
340 PRINT L$
350 REM INCREMENT LINE COUNT
360 C=C+1
370 REM GET NEXT LINE IF 400 LINES HAVE NOT BEEN
   TRANSFERRED
380 IF C<400 THEN GO TO 280
390 REM DATA TRANSFER AND STORAGE COMPLETE
400 PRINT "INDEXER LOADED WITH FILE";F$
410 REM CLOSE THE OPEN FILES
420 CLOSE
430 REM PROGRAM END
440 END
```

PROGRAM LISTING 3

```
10 REM THIS PROGRAM ALLOWS INTERACTIVE COMMU-
   NICATIONS BETWEEN THE
20 REM HOST AND THE INDEXER
30 REM CONFIGURE SERIAL PORT 1 FOR INDEXER COM-
   MUNICATIONS
40 REM INDEXER SET AT 9600 BAUD, 8 DATA BITS, 2 STOP
   BITS,AND
50 REM NO PARITY
60 OPEN "COM1:9600,N,8,2,CS,DS,CD" AS#1
70 PRINT #1, CHR$(17);
80 REM SET L26 PARAMETER IN ALL INDEXERS
90 PRINT #1,"<0 L26 0"
120 REM ENTER INDEXER COMMAND STRING
130 REM IF END IS ENTERED THEN PROGRAM IS TERMI-
   NATED
140 INPUT "ENTER INDEXER COMMAND";L$
150 IF L$="END" THEN GO TO 350
160 PRINT #1, CHR$(17);
170 REM OUTPUT INDEXER COMMAND STRING
180 PRINT #1,L$
190 REM TIME DELAY
200 FOR I=1 TO 25
210 NEXT I
220 REM READ INPUT BUFFER FOR DATA
230 IF EOF(1)=-1 THEN GO TO 140
240 REM DO NOT PRINT CHARACTER IF XOFF OR XON
250 PRINT #1, CHR$(17);
260 B$=INPUT$(1,#1)
270 IF B$=CHR$(17) THEN GO TO 230
280 IF B$=CHR$(19) THEN GO TO 230
290 REM
300 IF B$=CHR$(10) THEN PRINT B$;; GOSUB 360: GO TO
   230
310 REM PRINT INPUT CHARACTER ON DISPLAY
320 PRINT B$;
330 GO TO 200
340 REM PROGRAM END
350 END
360 REM THIS SUBROUTINE IS CALLED IF A MULTI-LINE
   TRANSFER HAS BEEN
370 REM COMMANDED. IT UTILIZES XON AND XOFF
380 IF EOF(1)=-1 THEN RETURN
390 REM OUTPUT XOFF
400 PRINT #1,CHR$(19);
410 REM INPUT CHARACTER
420 B$=INPUT$(1,#1)
430 REM DO NOT PRINT IF XOFF OR XON
440 IF B$=CHR$(17) THEN GO TO 380
450 IF B$=CHR$(19) THEN GO TO 380
460 REM
470 REM PRINT INPUT CHARACTER ON DISPLAY
480 PRINT B$;
490 IF EOF(1)=0 THEN GO TO 420
500 REM OUTPUT XON
510 PRINT #1,CHR$(17);
520 RETURN
```


SECTION 6: SPEED/TORQUE CURVES

TYPICAL PERFORMANCE CHARACTERISTICS




FULL/HALF STEP
M061-CF408 AND M061-LF408 MOTORS

TYPICAL PERFORMANCE CHARACTERISTICS




FULL/HALF-STEP
M062-CF402 AND M062-LF402 MOTORS


TYPICAL PERFORMANCE CHARACTERISTICS




FULL/HALF STEP
M063-CF401 AND M063-LF401 MOTORS



MICROSTEP
M061-CF408 AND M061-LF408 MOTORS




MICROSTEP
M062-CF402 AND M062-LF402 MOTORS




MICROSTEP
M063-CF401 AND M063-LF401 MOTORS

TYPICAL PERFORMANCE CHARACTERISTICS




FULL/HALF STEP
M091-FF401 MOTOR

TYPICAL PERFORMANCE CHARACTERISTICS




FULL/HALF-STEP
M092-FF401 MOTOR


TYPICAL PERFORMANCE CHARACTERISTICS




FULL/HALF STEP
M093-FF402 MOTOR



MICROSTEP
M091-FF401 MOTOR




MICROSTEP
M092-FF402 MOTOR




MICROSTEP
M093-FF402 MOTOR

TYPICAL PERFORMANCE CHARACTERISTICS




FULL//HALF STEP
M111-FF401 AND MX111-FF401 MOTORS

TYPICAL PERFORMANCE CHARACTERISTICS




FULL/HALF-STEP
M112-FF401 MOTOR


TYPICAL PERFORMANCE CHARACTERISTICS




FULL//HALF STEP
MH112-FJ4201 MOTOR



MICROSTEP
M111-FF401 AND MX111-FF401 MOTORS



MICROSTEP
M112-FF401 MOTOR



MICROSTEP
MH112-FJ4201 MOTOR

6.1 MOTOR PERFORMANCE

All stepping motors exhibit instability at their natural frequency and harmonics of that frequency. Typically, this instability will occur at speeds between 50 and 500 full steps per second and, depending on the dynamic motor load parameters, can cause excessive velocity modulation or improper positioning.

There are also other instabilities which may cause a loss of torque at stepping rates outside the range of natural resonance frequencies. One such instability is broadly identified as mid-range instability. This is identified by the dotted area (...) on the speed torque curves.

Usually, the dampening of the system and acceleration/deceleration through the resonance areas aids in reducing instability to a level that provides smooth shaft velocity and accurate positioning. If instability does cause unacceptable performance under actual operating conditions, the following techniques can be used to reduce velocity modulation.

1. Avoid constant speed operation at the motor's unstable frequencies. Select a base speed that is above the motor's resonant frequencies and adjust acceleration and deceleration to move the motor through unstable regions quickly.

2. The motor winding current can be reduced as discussed in Section 3.8. Lowering the current will reduce torque proportionally. The reduced energy delivered to the motor can decrease velocity modulation.

3. Use half-step mode of operation (3180-PI only). Note that this halves the shaft speed for a given input pulse rate. Microstepping (3180-PI10 and 3180-PI125) inherently provides smoother operation, and reduces the effects of mid-range instability.

SECTION 7: TROUBLESHOOTING

WARNING: Motors connected to this drive can develop high torque and large amounts of mechanical energy.

Keep clear of the motor shaft, and all parts mechanically linked to the motor shaft.

Turn off the power to the drive before performing work on parts mechanically coupled to the motor.

If installation and operation instructions have been followed carefully, this unit should perform correctly. If motor fails to step properly, the following checklist will be helpful.

In General:

- Check all installation wiring carefully for wiring errors or poor connections.
- Check to see that the proper voltage levels are being supplied to the unit.
- Be sure the motor is compatible for use with this unit.
- Check to see that baud rates, parity and other communications parameters are properly set.
- When connecting this unit to a terminal or host computer, be sure device addresses are correct.

7.1 IF MOTOR DIRECTION (CW, CCW) IS REVERSED, Check:

Connections to the Motor Connector may be reversed.

7.2 IF THE MOTOR MOTION IS ERRATIC, Check:

Supply voltage out of tolerance.

Motion parameters (low speed, acceleration/deceleration, jog speed, home speed, and feedrate) may need adjustment.

Operation in dotted area of speed-torque curve.

7.3 IF TORQUE IS LOW, Check:

AWO (All Windings Off) active or REDUCED CURRENT active. Improper supply voltage.

Operation in dotted area of speed-torque curve.

If a malfunction occurs that cannot be corrected by making these corrections, contact The Superior Electric Company.

APPENDIX

MICRO-SERIES SINGLE LINE PRESET INDEXER EMULATION

This Appendix provides two methods of emulating a one-line indexer function with a Superior Electric Micro-Series Indexer. Method 1 utilizes the MDI (line 000) mode to function as a one-liner indexer, while Method 2 requires programming of lines 1 and 2. An assumption was made that a Superior Electric SSP-100 programmer was interfaced to the Micro-Series Indexer, although any parallel data entry device (such as a programmable controller) can utilize these methods.

Only the required parameters and program lines are programmed; the other parameters and program lines retain their factory defaults as shown below:

Full Step Translator	1/10th Step Translator	1/125th Step Translator
L06 = 1	L06 = 1	L06 = 1
L07 = 0100	L08 = 0100	L07 = 0100
L08 = +	L08 = +	L08 = +
L09 = 0001000	L09 = 0010000	L09 = 0125000
L11 = 0002500	L11 = 0025000	L11 = 0312500
L12 = 0000250	L12 = 0002500	L12 = 0031250
L14 = 0001000	L14 = 0010000	L14 = 0125000
L17 = +00000000	L17 = +00000000	L17 = +00000000
L18 = -00000000	L18 = -00000000	L18 = -00000000
L19 = +00000000	L19 = +00000000	L19 = +00000000
L21 = 01	L21 = 01	L21 = 01
L22 = 9600	L22 = 9600	L22 = 9600
L23 = 8	L23 = 8	L23 = 8
L25 = 1	L25 = 1	L25 = 1
L26 = 0	L26 = 0	L26 = 0
L41 = 000	L41 = 000	L41 = 000
L44 = 0050	L44 = 0050	L44 = 0050
L45 = 0	L45 = 0	L45 = 0
L48 = 000	L48 = 000	L48 = 000
L49 = 00	L49 = 00	L49 = 00
L70 = 001	L70 = 010	L70 = 125

One-Line Indexer Emulation Comments

- Method 1 requires fewer set up steps than Method 2, but Method 2 simplifies the daily operations.
- Method 1 requires the feed rate to be loaded on power up if the power up default of the L09 parameter is not adequate, while Method 2 retains the feed rate in nonvolatile memory.
- The two methods are applicable to any Micro-Series Indexer.
- The power up default of incremental mode is assumed to remain unchanged.
- The user may find it easier to perform the set up operations via the RS232 serial port with a computer or terminal, or using the Superior Electric SSP-500 remote hand-held programmer.
- The set up is similar to the set up requirements of an IODD008 Modulynx indexer of the analog speed adjustment of a TBM or PIM module.
- The methods require Rev. C (4/87) or later indexer software revisions.
- If the time to load the data, which is 7 times the L07 value (a total of 700 milliseconds at factory default setting), is too long, then L07 can be altered as follows:
 - Select L code with SEL 4 = 1, SEL 2 = 0, and SEL 1 = 0.
 - Set the CODE DATA THUMBWHEELS to 007.
 - Set the strobe delay time (milliseconds) in the FIELD DATA THUMBWHEELS.
 - Activate the LOAD switch and release.
 - The strobe delay time has been entered into the L09 parameter.

One-Line Indexer: Method 1

A. Indexer Set Up – Done only once as all values are retained in nonvolatile memory.

1. L70 (Translator Resolution) Data Entry:

- Select L code with SEL4 = 1, SEL2 = 0, and SEL1 = 0.
- Set the CODE DATA THUMBWHEELS to 007.
- Set the translator resolution (1,2,10, or 125) in the FIELD DATA THUMBWHEELS.
- Activate the LOAD switch and release.
- The translator resolution has been entered into the L70 parameter.

2. L12 (Low Speed) Data Entry:

- Select L code with SEL4 = 1, SEL2 = 0, and SEL1 = 0.
- Set the CODE DATA THUMBWHEELS to 012.
- Set the low (base) speed (pulses/sec) in the FIELD DATA THUMBWHEELS.
- Activate the LOAD switch and release.
- The low (base) speed has been entered into the L12 parameter.

3. L11 (Acceleration/Deceleration) Data Entry:

- Select L code with SEL4 = 1, SEL2 = 0, and SEL1 = 0.
- Set the CODE DATA THUMBWHEELS to 011.
- Set the acceleration/deceleration rate (pulses/sec²) in the FIELD DATA THUMBWHEELS.
- Activate the LOAD switch and release.
- The acceleration/deceleration rate has been entered into the L11 parameter.

4. L09 (Jog Speed) Data Entry:

- Select L code with SEL4 = 1, SEL2 = 0, and SEL1 = 0.
- Set the CODE DATA THUMBWHEELS to 009.
- Set the low (base) speed (pulses/sec) in the FIELD DATA THUMBWHEELS.
- Activate the LOAD switch and release.
- The jog speed has been entered into the L09 parameter.
- Upon power up, the jog speed in L09 will be utilized as the feed rate.

B. Daily Operation

1. X (Move Distance) Data Entry:

- Select X code with SEL4 = 0, SEL2 = 1, and SEL1 = 0.
- Set the Distance (pulses) in the FIELD DATA THUMBWHEELS.
- Activate the LOAD switch and release.
- The distance has been entered into the X field.

2. F (Feed Rate) Data Entry: (skip to step 3 if the power up default of the L09 parameter is adequate)

- Select F code with SEL4 = 0, SEL2 = 1, and SEL1 = 1.
- Set the Feed Rate (pulses/sec) in the FIELD DATA THUMBWHEELS.
- Activate the LOAD switch and release.
- The Feed Rate has been entered into the F field.

3. Index Operation:

- Activate the CYCLE START switch and release.
- The motor indexes the distance entered.

4. The X and F values are retained until power is turned off.

Repeat steps 1 and 2 as necessary to edit the motion parameters, and then repeat step 3 to initiate motion.

One-Line Indexer: Method 2

A. **Indexer Set Up** — Done only once as all values are retained in nonvolatile memory.

1. L70 (Translator Resolution) Data Entry:

- A. Select L code with SEL4 = 1, SEL2 = 0, and SEL1 = 0.
- B. Set the CODE DATA THUMBWHEELS to 070.
- C. Set the translator resolution (1,2,10 or 125) in the FIELD DATA THUMBWHEELS.
- D. Activate the LOAD switch and release.
- E. The translator resolution has been entered into the L70 parameter.

2. L12 (Low Speed) Data Entry:

- A. Select L code with SEL4 = 1, SEL2 = 0, and SEL1 = 0.
- B. Set the CODE DATA THUMBWHEELS to 012.
- C. Set the low (base) speed (pulses/sec) in the FIELD DATA THUMBWHEELS.
- D. Activate the LOAD switch and release.
- E. The low (base) speed has been entered into the L12 parameter.

3. L11 (Acceleration/Deceleration) Data Entry:

- A. Select L code with SEL4 = 1, SEL2 = 0, and SEL1 = 0.
- B. Set the CODE DATA THUMBWHEELS to 011.
- C. Set the acceleration/deceleration rate (pulses/sec²) in the FIELD DATA THUMBWHEELS.
- D. Activate the LOAD switch and release.
- E. The acceleration/deceleration rate has been entered into the L11 parameter.

4. L09 (Jog Speed) Data Entry: (skip to step 5 if not utilizing jog function)

- A. Select L code with SEL4 = 1, SEL2 = 0, and SEL1 = 0.
- B. Set the CODE DATA THUMBWHEELS to 009.
- C. Set the low (base) speed (pulses/sec) in the FIELD DATA THUMBWHEELS.
- D. Activate the LOAD switch and release.
- E. The low (base) speed had been entered into the L12 parameter.

5. L06 (Program Execution Mode) Data Entry:

- A. Select L code with SEL4 = 1, SEL2 = 0, and SEL1 = 0.
- B. Set the CODE DATA THUMBWHEELS to 006.
- C. Set FIELD DATA THUMBWHEELS to 2.
- D. Activate the LOAD switch and release.
- E. The auto execution mode has been entered into the L06 parameter.

6. L41 (Autostart Line Number) Data Entry:

- A. Select L code with SEL4 = 1, SEL2 = 0, and SEL1 = 0.
- B. Set the CODE DATA THUMBWHEELS to 041.
- C. Set FIELD DATA THUMBWHEELS to 1.
- D. Activate the LOAD switch and release.
- E. The autostart line number has been entered into the L41 parameter.

7. Select line number 001:

- A. Select N code with SEL4 = 0, SEL2 = 0, and SEL1 = 0.
- B. Set the CODE DATA THUMBWHEELS to 001.
- C. Activate the LOAD switch and release.
- D. N001 has been selected.

8. Enter G36 (X code Strobe) on line number 001:

- A. Select G code with SEL4 = 0, SEL2 = 0, and SEL1 = 1.
- B. Set the CODE DATA THUMBWHEELS to 036.
- C. Activate the LOAD switch and release.
- D. G36 has been entered into the program.

9. F (Feed Rate) Data Entry:

- A. Select F code with SEL4 = 0, SEL2 = 1, and SEL1 = 1.
- B. Set the Feed Rate (pulses/sec) in the FIELD DATA THUMBWHEELS.
- C. Activate the LOAD switch and release.
- D. The Feed Rate has been entered into line number 1's F field.

10. Select Line Number 002:

- A. Select N code with SEL4 = 0, SEL2 = 0, and SEL1 = 0.
- B. Set the CODE DATA THUMBWHEELS to 002.
- C. Activate the LOAD switch and release.
- D. N002 has been selected.

11. Enter G30 (Program End) on line number 002:

- A. Select G code with SEL4 = 0, SEL2 = 0, and SEL1 = 1.
- B. Set the CODE DATA THUMBWHEELS to 030.
- C. Activate the LOAD switch and release.
- D. G30 has been entered into the program on line number 2.

B. Daily Operation

1. Index Operation:

- A. Set the Distance (pulses) in the FIELD DATA THUMBWHEELS.
- B. Activate the CYCLE START switch and release.
- C. The motor indexes the distance entered.

2. Repeat step 1 as necessary.

CODE SUMMARY

PARAMETERS		COMMANDS	
COMMAND FORMAT	FUNCTION	COMMAND FORMAT	FUNCTION
L06 n	EXECUTION FORMAT	H01	PROGRAM CYCLE START
L07 nnnn	STROBE DELAY TIME	H02	STEP MODE
L08 s	MECHANICAL HOME DIRECTION	H03	JOG MODE
L09 nnnnnnnn	JOG SPEED	H04	SET HIGH SPEED MODE
L11 nnnnnnnn	ACC/DCC	H05	SET LOW SPEED MODE
L12 nnnnnnnn	LOW SPEED	H06	CW DIR (Jog or Step cycle)
L14 nnnnnnnn	HOME SPEED	H07	CCW DIR (Jog or Step cycle)
L17 snnnnnnnn	MECHANICAL HOME OFFSET	H08	RETURN ELECTRICAL HOME
L18 snnnnnnnn	SOFTWARE CW LIMIT	H09	SET ELECTRICAL HOME
L19 snnnnnnnn	SOFTWARE CCW LIMIT	H10	RETURN MECHANICAL HOME
L21 nn	DEVICE ID	H11	CLEAR PRESENT PROGRAM LINE
L22 nnnn	BAUD RATE	H12	CLEAR ALL PROGRAM LINES
L23 n	WORD LENGTH	H13	TX PRESENT PROGRAM LINE
L25 n	PARITY	H14	TX ALL PROGRAM LINES
L26 n	RESPONSE FORMAT	H15	TX PRESENT PROGRAM NUMBER
L41 nnn	AUTO START LINE NUMBER	H16	TX PARAMETER
L44 nnnn	BETWEEN LINE DELAY	H17	TX ABSOLUTE POSITION
L45 n	LIMIT ENABLE/DISABLE	H18	TX MOTION STATUS
L48 nnn	PROGRAM LINE TRANSFER COUNT	H19	TX MODE STATUS
L49 nn	PARAMETER TRANSFER DESIGNATOR	H20	TX I/O STATUS
L70 nnn	RESOLUTION	H23	TX SOFTWARE REV LEVEL
		H24	ENABLE TRACE MODE
		H25	DISABLE TRACE MODE

COMMANDS

NOTE: TX is an abbreviation for "Transmit".

COMMAND FORMAT	FUNCTION
Xoff	SUSPEND RS232 TRANSMISSION
Xon	RESUME RS232 TRANSMISSION
^X	CANCEL LINE IN RS232 BUFFER
^H	BACKSPACE 1 CHARACTER IN RS232 BUFFER
<00	ATTENTION ALL DEVICES
<nn	ATTENTION DEVICE nn WITH RESPONSE (:) OR (=Xon)
*	MOTION CLEAR
\$	FEED HOLD OR JOG STOP
#	PROGRAM STOP

COMMAND FORMAT	FUNCTION
Nnnn	LINE NUMBER (000 THRU 400)
Xnnnnnnnnn	MOVE DISTANCE OR DATA FIELD FOR G04,G11,G20,G22,G47 CODES
Fnnnnnnn	FEED RATE OR DATA FIELD FOR G11,G20

COMMAND FORMAT	FUNCTION	X FIELD DATA	F FIELD DATA
G04 Xnnnn	DWELL	Dwell Time in milliseconds	
G11 Xnnnn Fnnnn	SUBROUTINE CALL	Line Number of Subroutine	
G20 Xnnnn Fnnnn	BRANCH ON INPUT CONDITION	Input Condition for Branch	
G22 Xnnnn	WAIT FOR INPUT CONDITION	Input Condition	
G30	END OF PROGRAM/RTS		
G31	PROGRAM STOP		
G36	STROBE X CODE DATA		
G37	STROBE N CODE DATA		
G47 Xnn	SET/RESET OUTPUT CONDITION	Output Condition	
G64	ENABLE REDUCED CURRENT MODE		
G65	DISABLE REDUCED CURRENT MODE		
G66	ENABLE BOOST CURRENT MODE		
G67	DISABLE BOOST CURRENT MODE		
G68	WINDINGS OFF		
G69	WINDINGS ON		
G76	RETURN TO ELECTRICAL HOME		
G77	SET ELECTRICAL HOME		
G78	RETURN TO MECHANICAL HOME		
G90	ABSOLUTE DIMENSION INPUT		
G91	INCREMENTAL DIMENSION INPUT		

NOTE: RTS is an abbreviation for "Return From Subroutine".

PROGRAM WORKSHEET

HARDENED INDEXER PROGRAMMING WORKSHEET

L CODE DATA	FUNCTION
L06 _	EXECUTION FORMAT
L07 - - -	STROBE DELAY TIME
L08 _	MECHANICAL HOME DIRECTION
L09 - - - -	JOG SPEED
L11 - - - - -	ACCELERATION/DECCELERATION
L12 - - - - -	LOW SPEED
L14 - - - - -	HOME SPEED
L17 - - - - -	MECHANICAL HOME OFFSET
L18 - - - - -	SOFTWARE CW LIMIT
L19 - - - - - -	SOFTWARE CCW LIMIT

L CODE DATA	FUNCTION
L21 - -	DEVICE ID
L22 _	BAUD RATE
L23 _	WORD LENGTH
L25 _	PARITY
L26 _	RESPONSE FORMAT
L41 - - -	AUTO START LINE
L44 - - - -	BETWEEN LINE DELAY
L45 _	LIMIT ENABLE/DISABLE
L70 - - -	RESOLUTION

PROGRAM DATA

DISTRIBUTION COAST-TO-COAST AND INTERNATIONAL

Superior Electric products are available nationwide through an extensive authorized distributor network. These distributors offer literature, technical assistance and a wide range of models off the shelf for fastest possible delivery.

In addition, Superior Electric sales engineers and manufacturers' representatives are conveniently located to provide prompt attention to customers' needs. Call the nearest office listed for ordering and application information or for the address of the closest authorized distributor.

IN U.S.A. and CANADA

383 Middle Street
Bristol, CT 06101
Tel: (203) 582-9561
TWX: 710-454-0682 – FAX: 203-589-2136
Customer Service: 1-800-227-6470
Product Application: 1-800-227-6471
FAX: 1-800-766-6366
Product Literature Request: 1-800-766-7171

IN EUROPE

Superior Electric Nederland B.V.
Koperwerf 33
2544 EM The Hague, Netherlands
Tel: 31 70 3 679590
TELEX: 31436 Supe nl
FAX: 011 31 70 3 296274

WARRANTY AND LIMITATION OF LIABILITY

Superior Electric (the "Company"), Bristol, Connecticut, warrants to the first end user purchaser (the "purchaser") of equipment manufactured by the Company that such equipment, if new, unused and in original unopened cartons at the time of purchase, will be free from defects in material and workmanship under normal use and service for a period of one year from date of shipment from the Company's factory or a warehouse of the Company in the event that the equipment is purchased from the Company or for a period of one year from the date of shipment from the business establishment of an authorized distributor of the Company in the event that the equipment is purchased from an authorized distributor.

THE COMPANY'S OBLIGATION UNDER THIS WARRANTY SHALL BE STRICTLY AND EXCLUSIVELY LIMITED TO REPAIRING OR REPLACING, AT THE FACTORY OR A SERVICE CENTER OF THE COMPANY, ANY SUCH EQUIPMENT OR PARTS THEREOF WHICH AN AUTHORIZED REPRESENTATIVE OF THE COMPANY FINDS TO BE DEFECTIVE IN MATERIAL OR WORKMANSHIP UNDER NORMAL USE AND SERVICE WITHIN SUCH PERIOD OF ONE YEAR. THE COMPANY RESERVES THE RIGHT TO SATISFY SUCH OBLIGATION IN FULL BY REFUNDING THE FULL PURCHASE PRICE OF ANY SUCH DEFECTIVE EQUIPMENT. This warranty does not apply to any equipment which has been tampered with or altered in any way, which has been improperly installed or which has been subject to misuse, neglect or accident.

THE FOREGOING WARRANTY IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, and of any other obligations or liabilities on the part of the Company; and no person is authorized to assume for the Company any other liability with respect to equipment manufactured by the Company. The Company shall have no liability with respect to equipment not of its manufacture. **THE COMPANY SHALL HAVE NO LIABILITY WHATSOEVER IN ANY EVENT FOR PAYMENT OF ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, WITHOUT LIMITATION, DAMAGES FOR INJURY TO ANY PERSON OR PROPERTY.**

Written authorization to return any equipment or parts thereof must be obtained from the Company. The Company shall not be responsible for any transportation charges.

IF FOR ANY REASON ANY OF THE FOREGOING PROVISIONS SHALL BE INEFFECTIVE, THE COMPANY'S LIABILITY FOR DAMAGES ARISING OUT OF ITS MANUFACTURE OR SALE OF EQUIPMENT, OR USE THEREOF, WHETHER SUCH LIABILITY IS BASED ON WARRANTY, CONTRACT, NEGLIGENCE, STRICT LIABILITY IN TORT OR OTHERWISE, SHALL NOT IN ANY EVENT EXCEED THE FULL PURCHASE PRICE OF SUCH EQUIPMENT.

Any action against the Company based upon any liability or obligation arising hereunder or under any law applicable to the sale of equipment, or the use thereof, must be commenced within one year after the cause of such action arises.

These products are sold subject to the standard Limitation of Liability and/or Warranty of The Superior Electric Company, The American Superior Electric Company, Ltd., or Superior Electric Nederland B.V.

The right to make engineering refinements on all products is reserved. Dimensions and other details are subject to change.



Superior Electric

® Bristol, Connecticut 06010-7488



TEL: (203) 582-9561 TELEX: 96-2446 TWX: 710-454-0682

Cable Address: SUPELEC FAX: (203) 589-2136